

## PARTS LIST

Note: The parts marked "Δ" may cause undue microwave exposure.

The parts marked "\*" are used in voltage more than 250V.

REF. NO.	PART NO.	DESCRIPTION	Q'TY	CODE
<b>ELECTRIC PARTS</b>				
1- 1	FPWBPA383WRKZ	Noise filter	1	AN
1- 2	QSOCOA026WRZZ	Oven lamp socket	1	AF
Δ* 1- 3	RV-MZA335WRZZ	Magnetron	2	BA
1- 4	FMOTEA495WRKZ	Blower motor	1	BF
* 1- 5	RTRN-A724WRZZ	Power transformer	2	BF
1- 6	FACCDAA112WRKZ	Power supply cord	1	BB
1- 7	FH-HZA070WRE0	Oven thermistor & Magnetron thermistor	2	AM
* 1- 8	FW-QZA117WRK0	High voltage rectifier assembly	1	AU
1- 9	FFS-BA033WRKZ	Monitor switch (V-5220Q) and fuse 20A assembly	2	**
1-10	QFS-TA015WRE0	Temperature fuse 120C (OVEN)	1	AG
1-11	QSW-MA085WRE0	Secondary interlock switch and Door sensing switch	3	AF
* 1-12	RC-QZA325WRZZ	High voltage capacitor	2	AP
1-13	RLMPTA081WRZZ	Oven lamp	1	AK
1-14	RMOTDA209WRE0	Stirrer motor	2	AR
1-15	QFS-TA014WRE0	Temperature fuse 150C (MG.)	2	AG
<b>CABINET PARTS</b>				
2- 1	FDAI-A275WRTZ	Base plate assembly	1	BC
2- 2	PSHEGA006WRE0	Rubber sheet A	2	AF
2- 3	PSHEGA007WRE0	Rubber sheet B	2	AE
2- 4	GCOVAA283WRW0	Rear cabinet	1	AX
2- 5	FPTASA064WRY0	Oven lamp access cover assembly	1	AN
2-5-1	PCUSUA585WRPZ	Cushion	1	AF
2- 6	GCABUA860WRPZ	Outer case cabinet	1	BD
2- 7	FFPF-A016WRK0	Vibration-proof sheet	1	AU
2- 8	TMAPCA772WRPZ	Schematic diagram	1	AE
<b>CONTROL PANEL PARTS</b>				
3- 1	DPWFPC452WRKZ	Control unit	1	BN
3- 1A	QCNCMA308DRE0	4-pin connector (CN-A)	1	AC
3- 1B	QCNCMA312DRE0	3-pin connector (CN-B)	1	AB
3- 1C	QCNCMA039DRE0	3-pin connector (CN-H)	1	AB
3- 1D	QCNCWA030DRE0	12-pin connector (CN-G)	1	AE
3- 1E	QLUGPA012DRE0	Tab terminal (TB1, TB2)	2	AB
C1	VCEAB51EW228M	Capacitor 2200 uF 25V	1	AE
C2	VCKYD11HF104Z	Capacitor 0.1 uF 50V	1	AB
C3	VCEAB31AW476M	Capacitor 47 uF 10V	1	AA
C4	VCKYD11HF104Z	Capacitor 0.1 uF 50V	1	AB
C5	VCEAB31AW476M	Capacitor 47 uF 10V	1	AA
C6	VCKYD11HF104Z	Capacitor 0.1 uF 50V	1	AB
C7	VCKYD11CY103N	Capacitor 0.01 uF 16V	1	AA
C8-9	VCKYD11HF104Z	Capacitor 0.1 uF 50V	2	AB
C20	VCEAB31HW104M	Capacitor 0.1 uF 50V	1	AM
C21	VCEAB31EW106M	Capacitor 10 uF 25V	1	AA
C30	VCEAB31AW476M	Capacitor 47 uF 10V	1	AA
C31	VCKYD11CY103N	Capacitor 0.01 uF 16V	1	AA
C60	VCKYD11HF104Z	Capacitor 0.1 uF 50V	1	AB
C61	VCKYD11CY103N	Capacitor 0.01 uF 16V	1	AA
C62	VRD-Q12EF104J	Resistor 100k ohm 1/4W	1	AA
C63	VCKYD11CY103N	Capacitor 0.01 uF 16V	1	AA
C64	VRD-Q12EF562J	Resistor 5.6k ohm 1/4W	1	AA
C70	VCKYD11CY103N	Capacitor 0.01 uF 16V	1	AA
C100	VCEAB31AW476M	Capacitor 47 uF 10V	1	AA
C101	VCKYD11CY103N	Capacitor 0.01 uF 16V	1	AA
CF1	RCRS-A010DRE0	Ceramic resonator CST4.00MGW	1	AD
D1-4	VHD10EDB10+-1T	Diode (10EDB10)	4	AB
D20-22	VHD1SS270A/-1	Diode (1SS270A)	3	AA
D23	VHD10EDB10+-1T	Diode (10EDB10)	1	AB
D70	VHD1SS270A/-1	Diode (1SS270A)	1	AA
D100-101	VHD1SS270A/-1	Diode (1SS270A)	2	AA
IC1	RH-IZA633DRE0	LSI	1	AW
IC2	RH-IZA980DRE0	IC (AT24C02-10PC2.5)	1	AN
IC3	RIC--A025BDE0	IC (KID65004AP)	1	AE
LED1	VHPSL3966T/1B	Light emitting diode	1	AS
Q1	RIC--A022BDE0	IC (KIA7805PI)	1	AE
Q2	VSDTA123ES/-3	Transistor (DTA123ES)	1	AA
Q3	RH-TZA036CBE0	Transistor (KRC101M)	1	AA

REF. NO.	PART NO.	DESCRIPTION	Q'TY	CODE
Q20	VSDTB143ES/-3	Transistor (DTB143ES)	1	AC
Q21	RH-TZA036CBE0	Transistor (KRC101M)	1	AA
Q22-23	VSDTD143ES/-3	Transistor (DTD143ES)	2	AC
Q60	RH-TZA037CBE0	Transistor (KRA101M)	1	AA
R3-5	VRD-Q12EF472J	Resistor 4.7k ohm 1/4W	3	AA
R30	VRD-Q12EF101J	Resistor 100 ohm 1/4W	1	AA
R31	VRD-Q12EF153J	Resistor 15k ohm 1/4W	1	AA
R32	VRD-Q12EF272J	Resistor 2.7k ohm 1/4W	1	AA
R33	VRD-Q12EF472J	Resistor 4.7k ohm 1/4W	1	AA
R40	VRD-Q12EF272J	Resistor 2.7k ohm 1/4W	1	AA
R50-58	VRD-Q12EF101J	Resistor 100 ohm 1/4W	9	AA
R60	VRD-Q12EF112J	Resistor 1.1k ohm 1/4W	1	AA
R61	VRD-Q12EF472J	Resistor 4.7k ohm 1/4W	1	AA
R62	VRD-Q12EF333J	Resistor 33k ohm 1/4W	1	AC
R63	VRD-Q12EF272J	Resistor 2.7k ohm 1/4W	1	AA
R64	VRD-Q12EF472J	Resistor 4.7k ohm 1/4W	1	AA
R65	VRD-Q12EF682J	Resistor 6.8k ohm 1/4W	1	AA
R66	VRD-Q12EF472J	Resistor 4.7k ohm 1/4W	1	AA
R70-71	VRD-Q12EF472J	Resistor 4.7k ohm 1/4W	2	AA
R80-88	VRD-Q12EF472J	Resistor 4.7k ohm 1/4W	9	AA
R100	VRN-R12EK821F	Resistor 820 ohm (F) 1/4W	1	AA
R101	VRD-Q12EF333J	Resistor 33k ohm 1/4W	1	AG
R102	VRD-Q12EF472J	Resistor 4.7k ohm 1/4W	1	AA
RY1	RRLY-A071DRE0	Relay (OJE-SS-112LM)	1	AG
RY2-3	RRLY-A094DRE0	Relay (OMIF-S-112LM)	2	AN
SP1	RALM-A014DRE0	Buzzer (PKM22EPT)	1	AG
T1	RTRNPA094DRE0	Touch control transformer	1	AQ
CT1	RTRN-026CHRE0	Current transformer	1	AH
VRS1-2	RH-VZA034DRE0	Varistor (10G471K)	2	AD
ZD2	VHEHZ4A2///-1	Zener diode (HZ4A2)	1	AA
3- 2	PPLNCB468WRK0	Control panel frame with key unit	1	AZ
3- 2-1	FUNTKA773WRE0	Key unit	1	AT
3- 2-2	HDECAA195WRP0	Decoration metal fittings	1	AP
3- 2-3	PCUSUA417WRP0	Cushion	1	AB
3- 3	LANGTA243WRW0	Control panel mounting angle	1	AF
3- 4	XEPSD30P10XS0	Screw; control unit mounting	5	AA
3- 5	XEPSD40P12000	Screw; control panel mounting angle mounting	2	AA
3- 6	LX-BZA138WREZ	Screw; decoration panel mounting for earth	1	AB

#### OVEN PARTS

	4- 1	PGLSPA632WREZ	Lamp glass	1	AG
	4- 2	FDUC-A345WRYO	Exhaust duct assembly	1	AP
Δ	4- 3	*****	Oven cavity (Not a replaceable part)	1	--
	4- 4	PFILWA063WRPZ	Oven light screen (Inside)	1	AD
	4- 5	MLEVPA153WRP0	Switch lever A	1	AC
	4- 6	MLEVPA154WRP0	Switch lever B	1	AC
	4- 7	MLEVPA155WRP0	Switch lever C	1	AC
	4- 8	MSPRCA075WRE0	Switch spring A	1	AB
	4- 9	MSPRCA076WRE0	Switch spring B	2	AB
Δ	4-10	PHOK-A081WRP0	Latch hook	1	AP
Δ	4-11	MHNG-A216WRM0	Lower oven hinge	1	AG
	4-12	MSPRCA101WRE0	Switch lever spring C	1	AC
	4-13	PCUSU0407WRP0	Cushion	2	AA
	4-14	PGLSPA063WRYO	Ceramic shelf	1	BF
	4-15	FPLT-A013WRYZ	Stirrer antenna upper assembly	1	AX
	4-16	FPLT-A009WRY0	Stirrer antenna lower assembly	1	AV
	4-17	LANGKA762WRP0	Partition angle R	1	AB
	4-18	LANGQA228WRW0	Oven lamp mounting plate	1	AF
	4-19	LENDKA075WRP0	Capacitor holder	1	AD
	4-20	PGIDHA054WRW0	Water-proof cover	1	AF
	4-21	NSFTPA031WRP0	Antenna motor shaft	2	AH
	4-22	LANGQA622WRPZ	Noise filter angle	1	AK
	4-23	PCUSUA417WRP0	Cushion	1	AB
Δ	4-24	MHNG-A215WRM0	Upper oven hinge	1	AG
	4-25	PCUSUA413WRP0	Cushion	1	AG
	4-26	PCUSUA415WRP0	Cushion	1	AC
	4-27	PDUC-A729WRP0	Air duct	1	AL
	4-28	PDUC-A564WRW0	Mg exhaust duct	1	AP
	4-29	PCUSUA414WRP0	Cushion	1	AD
	4-30	LANGKA679WRPZ	Fixing angle S	1	AD
	4-31	HDECQA147WRM0	Corner cap right	1	AE
	4-32	LANGFA195WRW0	Chassis support	1	AH
	4-33	LBSHC0006YBEO	Cord bushing	1	AD
	4-34	LANGQA593WRPZ	Blower motor angle	1	AH

REF. NO.	PART NO.	DESCRIPTION	Q'TY	CODE
4-35	FFIL-A005WRK0	Air intake filter assembly	1	AS
4-36	HDECEA001WRP0	Decoration sash	1	AR
4-37	HDECQA146WRM0	Corner cap left	1	AE
4-38	PCUSGA409WRP0	Cushion	2	AE
4-39	PCOVPA310WRP0	Splash cover	1	AZ
4-40	LANGQA512WRP0	Thermistor angle	1	AE
4-41	LANGTA408WRWZ	Lamp glass mounting plate	1	AK
4-42	PCUSUA626WREZ	Cushion	1	AC
4-43	PCUSUA268WRP0	Cushion	1	AA

#### DOOR PARTS

Δ	5	CDORFA996WRKZ	Door assembly	1	BV
Δ	5- 1	DDORFB101WRKZ	Door panel assembly	1	BM
	5- 2	GCOVAA242WRY0	Door case	1	BD
	5- 3	FHNDMA011WRY0	Door lever assembly	1	AP
Δ	5- 4	GCOVHA350WRF0	Choke cover	1	AR
	5- 5	JHNDMA039WRM0	Door handle	1	AX
	5- 6	LANGKA766WRP0	Outside window fixing plate	2	AF
	5- 7	PCUSGA430WRP0	Cushion	2	AM
	5- 8	PGLSPA457WRE0	Door glass	1	AV
	5- 9	PPACGA142WRP0	Door case packing	2	AF
	5-10	PGID-0024WRF0	handle guide	4	AC
	5-11	PGID-0025WRF0	Handle spacer	1	AC
	5-12	XPPSD40P08K00	Screw : 4mm x 8mm	3	AA
	5-13	XHTSD40P08RV0	Screw : 4mm x 8mm	4	AA
	5-14	FANGKA200WRY0	Latch fixing angle	1	AQ
	5-15	FLEVPA019WRY0	Joint lever	1	AP
Δ	5-16	LSTPCA002WRM0	Latch head	2	AM
	5-17	MLEVPA220WRP0	Head lever	1	AM
	5-18	MSPRCA097WRE0	Latch spring	1	AC
	5-19	HBDGCA120WREZ	Door badge	1	AF
	5-20	XBPSD40P10K00	Screw : 4mm x 10mm	2	AA
	5-21	PCUSGA486WRP0	Handle cushion	1	AM
	5-22	PSPA-A102WRE0	Door case spacer	2	AE

#### MISCELLANEOUS

	6- 1	TINSEB071WRRZ	Instruction manual	1	AH
	6- 2	TLAEHA024WRF0	Menu sticker	1	AH
	6- 3	FW-VZC037WREZ	Switch harness	1	AS
	6- 4	FW-VZC036WREZ	Main wire harness	1	BG
	6- 5	LHLDWQ005YBE0	Purse lock LL	1	AA
	6- 6	LBNDKA079WRE0	Wire holder	2	AB
	6- 7	TCAUAA289WRRZ	DHHS caution label in French	1	AD
	6- 8	TCAUAA130WRR0	Lamp caution	1	AC
*	6- 9	QW-QZA238WRE0	High voltage wire	2	AF
	6-10	TCAUAA288WRRZ	Monitor caution label	1	AD
	6-11	TCAUA0165WRR0	DHHS caution label	1	AB
	6-12	FW-VZC039WREZ	Supply harness	1	AL
	6-13	LHOLDA004WRE0	Cord holder	1	AA
	6-14	TCAUAA181WRR0	Filter caution label	1	AC
	6-15	TCAUAA165WRR0	User caution	1	AC
	6-16	LHLDWQ004YBE0	Purse lock L	1	AA

#### SCRE,NUTS AND WASHERS

	7- 1	XCEWW30P08000	Screw : 3mm x 8mm	6	AB
	7- 2	XBPSD30P28KS0	Screw : 3mm x 28mm	2	AA
	7- 3	XNESD30-24000	Nut : 3mm x 2.4mm	2	AA
	7- 4	LX-BZA164WREZ	Special screw	12	AA
	7- 5	LX-BZA116WRE0	Special screw	2	AD
	7- 6	XOTSD40P10RV0	Screw : 4mm x 10mm	3	AA
	7- 7	LX-CZA038WRE0	Special screw	1	AA
	7- 8	XOTSD40P08000	Screw : 4mm x 8mm	6	AA
	7- 9	XCHWW40P10000	Scerw : 4mm x 10mm	2	AA
	7-10	LX-EZA004WRE0	Special screw	2	AA
	7-11	LX-BZA152WREZ	Special screw	7	AB
	7-12	LX-BZA138WREZ	Special screw	7	AB
	7-13	LX-BZA132WREZ	Special screw	4	AB
	7-14	LX-BZA041WRE0	Specail screw	2	AA
	7-15	XJPSD40P10000	Screw : 4mm x 10mm	2	AA
	7-16	XOTWW40P08000	Screw : 4mm x 8mm	32	AB



