

BDV-E2100/E3100/E4100/ E6100

SERVICE MANUAL

Ver. 1.2 2013.07

- BDV-E2100/E3100/E4100/E6100 are composed of following models.
As service manuals are issued for each component model, please refer to them.

COMPONENT MODEL NAME

	BDV-E2100	BDV-E3100	BDV-E4100	BDV-E6100
BLU-RAY DISC/ DVD receiver	HBD-E2100	HBD-E3100	HBD-E4100	HBD-E6100
Front speaker	SS-TSB121	SS-TSB122	SS-TSB123	SS-TSB123
Center speaker	SS-CTB121	SS-CTB122	SS-CTB122	SS-CTB122
Surround speaker	SS-TSB121	SS-TSB122	SS-TSB122	SS-TSB123
Subwoofer	SS-WSB122	SS-WSB123	SS-WSB123	SS-WSB123

SPECIFICATIONS

Power requirements	US and Canadian models: 120 VAC, 60 Hz Taiwan model: 120 V AC, 50/60 Hz Latin-American, 110 – 240 V AC area in E model and PX models: 110 V – 240 V AC, 50/60 Hz Saudi Arabia model: 127 V – 240 V AC, 50/60 Hz Other models: 220 V – 240 V AC, 50/60 Hz
Power consumption	On: 95 W Standby: 0.3 W
Dimensions (w/h/d) (approx.)	430 mm × 50.5 mm × 296 mm (17 in × 2 in × 11 $\frac{3}{4}$ in) incl. projecting parts
Mass (approx.)	2.7 kg (5 lb 16 oz)

Design and specifications are subject to change without notice.

- Standby power consumption: 0.3W.
- Over 85% power efficiency of amplifier block is achieved with the full digital amplifier, S-Master.

Unpacking

- Operating Instructions (Australian, South African, Saudi Arabia, Chinese, Thai, Taiwan, UK, US, Canadian, Russian, Latin-American, Singapore, 240 V AC area in E model, 220 – 240 V AC area in E model, 110 – 240 V AC area in E model and PX models)
- Quick Setup Guide
- Speaker Installation Guide
- Reference Guide (AEP model)
- Remote control (1)
- R6 (size AA) batteries (2)
- FM wire antenna (aerial) (1)
- High Speed HDMI cable (1) (Latin-American, 110 – 240 V AC area in E model, Chinese, Thai, Taiwan, Saudi Arabia 220 – 240 V AC area in E model, 240 V AC area in E model (except South African) and Singapore models)
- Front speakers (2)
- Surround speakers (2)
- Center speaker (1)
- Subwoofer (1)
- Speaker-bottom covers (2) (BDV-E4100), (4) (BDV-E6100)
- Bases (2) (BDV-E4100), (4) (BDV-E6100)
- Lower parts of the front speakers (2) (BDV-E4100)
- Lower parts of the front and surround speakers (4) (BDV-E6100)
- Screws (large) (2) (BDV-E4100), (4) (BDV-E6100)
- Screws (small) (8) (BDV-E4100), (16) (BDV-E6100)

– Refer to next page for accessories list –

BLU-RAY DISC/DVD HOME THEATRE SYSTEM

9-890-610-03

2013G80-1

© 2013.07

Sony Corporation

Published by Sony EMCS (Malaysia) PG Tec

SONY®

US Model

BDV-E2100/E3100

Canadian Model

E Model

BDV-E2100/E3100/E4100/ E6100

AEP Model

Taiwan Model

BDV-E2100/E4100/E6100

UK Model

BDV-E2100/E3100/E4100

Russian Model

Chinese Model

BDV-E4100/E6100

Australian Model

BDV-E2100/E6100

Saudi Arabia Model

Thai Model

BDV-E3100/E4100/E6100

South African Model

BDV-E2100/E3100/E6100

PX Model

BDV-E2100


ACCESSORIES

Part No.	Description	Remark
4-446-733-11	MANUAL, INSTRUCTION (ENGLISH) (US, CND)	
4-446-733-21	MANUAL, INSTRUCTION (FRENCH (CANADIAN)) (CND)	
4-446-733-31	MANUAL, INSTRUCTION (SPANISH (LATIN)) (US)	
4-446-733-41	MANUAL, INSTRUCTION (ENGLISH) (PX)	
4-446-733-51	MANUAL, INSTRUCTION (SPANISH (LATIN)) (MX6, E32)	
4-446-733-61	MANUAL, INSTRUCTION (ENGLISH/TRADITIONAL CHINESE)	(SP)
4-446-733-72	MANUAL, INSTRUCTION (RUSSIAN/UKRAINIAN) (RU)	
4-446-734-13	MANUAL, INSTRUCTION (ENGLISH) (E3, SAF, AUS, E12)	
4-446-734-13	MANUAL, INSTRUCTION (WEB) (ENGLISH) (UK)	
4-446-734-21	MANUAL, INSTRUCTION (FRENCH/ARABIC/PERSIAN) (E3)	
4-446-734-31	MANUAL, INSTRUCTION (ENGLISH/ARABIC) (EA)	
4-446-734-41	MANUAL, INSTRUCTION (SIMPLIFIED CHINESE) (CH)	
4-446-734-51	MANUAL, INSTRUCTION (TRADITIONAL CHINESE) (TW)	
4-446-734-61	MANUAL, INSTRUCTION (THAI) (TH)	
4-446-735-11	MANUAL, INSTRUCTION (WEB) (FRENCH) (AEP)	
4-446-735-21	MANUAL, INSTRUCTION (WEB) (SPANISH) (AEP)	
4-446-735-31	MANUAL, INSTRUCTION (WEB) (GERMAN) (AEP)	
4-446-735-41	MANUAL, INSTRUCTION (WEB) (DUTCH) (AEP)	
4-446-735-51	MANUAL, INSTRUCTION (WEB) (ITALIAN) (AEP)	
4-446-735-61	MANUAL, INSTRUCTION (WEB) (POLISH) (AEP)	
4-446-736-11	MANUAL, INSTRUCTION (WEB) (PORTUGUESE) (AEP)	
4-446-736-21	MANUAL, INSTRUCTION (WEB) (SWEDISH) (AEP)	
4-446-736-31	MANUAL, INSTRUCTION (WEB) (DANISH/FINNISH) (AEP)	
4-446-736-41	MANUAL, INSTRUCTION (WEB) (GREEK) (AEP)	
4-446-736-51	MANUAL, INSTRUCTION (WEB) (CZECH/HUNGARIAN) (AEP)	
4-446-736-61	MANUAL, INSTRUCTION (WEB) (TURKISH) (AEP)	
4-446-736-71	MANUAL, INSTRUCTION (WEB) (SLOVAKIAN) (AEP)	

- Abbreviation
 - AUS : Australian model
 - CH : Chinese model
 - CND : Canadian model
 - E3 : 240 V AC area in E model
 - E12 : 220 – 240 V AC area in E model
 - E32 : 110 – 240 V AC area in E model
 - EA : Saudi Arabia model
 - MX6 : Latin-American model
 - PX : PX model
 - RU : Russian model
 - SAF : South African model
 - SP : Singapore model
 - TH : Thai model
 - TW : Taiwan model

– Continued on next page –

Ref. No.	Part No.	Description	Remark
1	1-491-938-11	REMOTE COMMANDER (including BATTERY LID) (RM-ADP091) (SP, RU)	
1	1-491-939-11	REMOTE COMMANDER (including BATTERY LID) (RM-ADP089) (US, CND, PX)	
1	1-491-940-11	REMOTE COMMANDER (including BATTERY LID) (RM-ADP090) (AEP, UK, E3, SAF, TW, AUS, EA, TH, E12, CH)	
1	1-491-956-11	REMOTE COMMANDER (including BATTERY LID) (RM-ADP096) (MX6, E32)	
2	1-754-852-11	ANTENNA (FM) (FM wire antenna (aerial))	
3	1-835-855-31	CORD WITH CONNECTOR (HDMI CABLE) (High Speed HDMI cable) (E3, SP, TW, MX6, EA, TH, E12, E32, CH)	
4	4-162-924-11	FOOT (ST) (E4100/E6100: 12 pieces)	
5	4-442-654-01	BASE, TOP (E4100/E6100: 2 pieces)	
6	4-442-659-01	BASE, BOTTOM (E4100/E6100: 2 pieces)	
7	4-443-771-01	COVER, BOTTOM (Speaker-bottom covers) (E4100: 2 pieces/E6100: 4 pieces)	
8	7-682-562-09	SCREW +B 4X10 (Screw: black) (E4100: 8 pieces/E6100: 16 pieces)	
9	7-682-973-31	SCREW +PSW 5X14 (Screw: silver) (E4100: 2 pieces/E6100: 4 pieces)	
10	7-685-646-71	SCREW +BVTP 3X8 TYPE2 IT-3 (E4100/E6100: 12 pieces)	
11	A-1901-102-A	STAND ASSY (Lower parts of the front speakers (E4100: 2 pieces)/ Lower parts of the front and surround speakers (E6100: 4 pieces))	



- Abbreviation
 - AUS : Australian model
 - CH : Chinese model
 - CND : Canadian model
 - E3 : 240 V AC area in E model
 - E12 : 220 – 240 V AC area in E model
 - E32 : 110 – 240 V AC area in E model
 - EA : Saudi Arabia model
 - MX6 : Latin-American model
 - PX : PX model
 - RU : Russian model
 - SAF : South African model
 - SP : Singapore model
 - TH : Thai model
 - TW : Taiwan model

REVISION HISTORY

Clicking the version allows you to jump to the revised page.

Also, clicking the version at the top of the revised page allows you to jump to the next revised page.

[illegible]