

DAV-TZ140

SERVICE MANUAL

Ver. 1.2 2013.09

US Model
Canadian Model
AEP Model
UK Model
E Model
Australian Model

- DAV-TZ140 is composed of following models.
As service manuals are issued for each component model, please refer to them.

COMPONENT MODEL NAME

COMPONENT	MODEL NAME
	DAV-TZ140
DVD receiver	HBD-TZ140
Front speaker	SS-TS121
Center speaker	SS-CT121
Surround speaker	SS-TS121
Subwoofer	SS-WS121

SPECIFICATIONS

General

Power requirements

North American and Mexican models:
120 V AC, 60 Hz

Latin American models:

110 V - 240 V AC,
50/60 Hz

Other models:
220 V - 240 V AC,
50/60 Hz

Power consumption

North American and Mexican models:

On: 29 W

Standby: 0.4 W*

Other models:
On: 34 W
Standby: 0.5 W*

* Valid when the system is in the following status:

— [Control for HDMI] is set to [Off].

Dimensions (approx.) 340 mm × 56 mm ×
325 mm (13 1/2 in ×
2 1/4 in × 12 7/8 in)
(w/h/d) incl. projecting
parts

Mass (approx.) 2.1 kg (4 lb 11 oz)

Design and specifications are subject to change without notice.

• Abbreviation


AR : Argentina model
AU1 : Australian and New Zealand models
BR : Brazilian model
CND : Canadian model
E3 : Middle East & African models (Except South African)
E32 : Latin American model (Except Brazilian, Mexican)
EA : Saudi Arabia model
MX : Mexican model
PH : Philippines model
RU : Russian model
SAF : South African model
SP1 : South East Asian (Except Indian, Thai),
East Asian (Hong Kong, Mongolia),
Oceanian (Except Australian, New Zealand) models
TH : Thai model

Unpacking

- Main unit (1)
- Subwoofer (1)
- Speakers (5)
- FM wire antenna (aerial) (1)
- Video cord (1)
(Included only certain areas)
- Operating Instructions
- Remote commander (remote) (1)
- R6 (Size AA) batteries (2)
(US model only)
- High Speed HDMI cable (1)
(Included only certain areas)

ACCESSORIES

Ref. No.	Part No.	Description	Remark
	4-299-353-12	MANUAL, INSTRUCTION (ENGLISH) (US, CND, UK, E3, SAF, EA, SP1, PH, AU1)	
	4-299-353-22	MANUAL, INSTRUCTION (FRENCH) (CND, AEP, E3)	
	4-299-353-33	MANUAL, INSTRUCTION (SPANISH) (US, AEP, E32, MX)	
	4-299-353-43	MANUAL, INSTRUCTION (POLISH) (AEP)	
	4-299-353-52	MANUAL, INSTRUCTION (GERMAN) (AEP)	
	4-299-353-62	MANUAL, INSTRUCTION (DUTCH) (AEP)	
	4-299-353-72	MANUAL, INSTRUCTION (ITALIAN) (AEP)	
	4-299-353-82	MANUAL, INSTRUCTION (ARABIC) (E3, EA)	
	4-299-353-91	MANUAL, INSTRUCTION (SPANISH) (AR)	
	4-299-354-11	MANUAL, INSTRUCTION (RUSSIAN) (RU)	
	4-299-354-21	MANUAL, INSTRUCTION (UKRAINIAN) (RU)	
	4-299-354-31	MANUAL, INSTRUCTION (TRADITIONAL CHINESE) (SP1)	
	4-299-354-41	MANUAL, INSTRUCTION (THAI) (TH)	
	4-299-354-52	MANUAL, INSTRUCTION (PORTUGUESE) (BR)	
	4-299-355-11	MANUAL, INSTRUCTION (DANISH) (AEP)	
	4-299-355-21	MANUAL, INSTRUCTION (FINNISH) (AEP)	
	4-299-355-31	MANUAL, INSTRUCTION (PORTUGUESE) (AEP)	
	4-299-355-41	MANUAL, INSTRUCTION (SWEDISH) (AEP)	
	4-299-356-11	MANUAL, INSTRUCTION (GREEK) (AEP)	
	4-299-356-21	MANUAL, INSTRUCTION (CZECH) (AEP)	
	4-299-356-31	MANUAL, INSTRUCTION (HUNGARIAN) (AEP)	
	4-299-356-41	MANUAL, INSTRUCTION (TURKISH) (AEP)	
	4-299-356-51	MANUAL, INSTRUCTION (SLOVAKIAN) (AEP)	
1	1-489-973-11	REMOTE COMMANDER (RM-ADU138)	
2	9-885-166-93	FM ANTENNA (FM wire antenna (aerial))	
3	9-885-167-27	RCA CABLE (Video cord) (EXCEPT E32, SP1, AR, TH, PH)	
4	9-885-167-26	HDMI CABLE E32 (High Speed HDMI cable) (SP1)	
4	9-885-167-72	HDMI CABLE (High Speed HDMI cable) (E32, BR, AR, TH, PH)	



DVD HOME THEATRE SYSTEM

9-893-389-03

2013I33-1

© 2013.09

Sony Corporation

Published by Sony Techno Create Corporation

SONY®

