

HT-6600DP

SERVICE MANUAL

*US Model
Canadian Model*

Ver 1.1 2003.07

- HT-6600DP is composed of following models.
As for the service manual, it is issued for each component model, then, please refer to them.

COMPONENT MODEL NAME

	HT-6600DP
FM STEREO FM-AM RECEIVER	STR-K850P
DVD PLAYER	DVP-NC665P
PACKAGE SPEAKER	SS-CRP95
CENTER SPEAKER	SS-CNP95
SURROUND SPEAKER	SS-MSP95
SUB WOOFER SPEAKER	SA-WMSP85

PARTS LIST

<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>
	ACCESSORIES *****	
1-477-793-11	COMMANDER, STANDARD (RM-PP412)	
1-501-374-12	ANTENNA, LOOP (AM)	
1-751-347-13	CORD, CONNECTION (10m)(FOR SPEAKER)	
1-751-598-53	CORD, CONNECTION (PIN-PIN) (MONAURAL CORD)	
1-769-433-62	CORD, SPEAKER (3.5m)(FOR SPEAKER)	
1-793-184-21	CONNECTOR (F TYPE ADAPTOR) (FM)	
1-823-135-13	CORD (CONNECTION) (COAXIAL DIGITAL CORD)	
3-071-119-01	COVER, BATTERY (FOR RM-PP412)	
4-235-237-01	FOOT (FOR SUB WOOFER)	
4-244-560-11	INSTRUCTION MANUAL (ENGLISH)	
4-244-560-21	INSTRUCTION MANUAL (FRENCH)(Canadian)	
4-244-915-01	FOOT (FOR SURROUND SPEAKER)	

HOME THEATER SYSTEM

SONY®

9-877-409-02
2003G16-1
© 2003.07

Sony Corporation
Home Audio Company
Published by Sony Engineering Corporation

