

HT-SF2000/SS2000

SERVICE MANUAL

Ver. 1.0 2007.07

US Model
HT-SF2000/SS2000

Canadian Model
AEP Model
UK Model
HT-SF2000

- HT-SF2000/SS2000 are composed of following models.
As service manuals are issued for each component model, please refer to them.

COMPONENT MODEL NAME

	HT-SF2000	HT-SS2000
Multi channel AV receiver	STR-KS2000	
Front speaker	SS-MSP2200	SS-MSP1200
Center speaker	SS-CNP2200	SS-CNP1200
Surround speaker	SS-SRP2200	SS-SRP1200
Sub woofer	SS-WP2200	SS-WP1200

SPECIFICATIONS

Power requirements

Area code	Power requirements
U, UC	120 V AC, 60 Hz
CEL, CEK	230 V AC, 50/60 Hz

Power output (DIGITAL MEDIA PORT)

DC OUT: 5 V, 700 mA

Power consumption

Area code	Power consumption
U, CEL, CEK	165 W
UC	165 W (for USA) 245 VA (for CANADA)

Power consumption (during standby mode)

0.3 W (When
"CONTROL" in VIDEO
menu is set to "CTRL
OFF")

Dimensions (w/h/d) (Approx.)

430 × 66.5 × 333 mm
(17 × 2 5/8 × 13 1/4 inches)
including projecting parts
and controls

Mass (Approx.) 3.6 kg (7 lb 15 oz)

Supplied speakers

Front speakers (2)
Center speaker (1)
Surround speakers (2)
Sub woofer (1)

Supplied accessories

FM wire antenna (1)
AM loop antenna (1)
Remote commander RM-AAU017 (1)
R6 (size-AA) batteries (2)
Optimizer microphone (ECM-AC2) (1)
Speaker cords (5)
Coaxial digital cord (1)
Foot pads
•Speakers
– HT-SS2000 only (20)
– HT-SF2000 only (4)
•Sub woofer (4)

Design and specifications are subject to
change without notice.

ACCESSORIES

Part No.	Description	Remark
1-480-099-21	STANDARD COMMANDER (RM-AAU017)	
1-501-374-12	ANTENNA, LOOP (AM loop antenna)	
1-501-807-12	ANTENNA (FM) (FM wire antenna) (SF2000: AEP, UK)	
1-542-670-11	MEASUREMENT MIC (MONO) (Optimizer microphone: ECM-AC2)	
1-793-184-23	CONNECTOR (F TYPE ADAPTOR) (FM wire antenna) (SF2000: US, Canadian/SS2000)	
1-823-135-13	CORD (CONNECTION) (Coaxial digital cord)	

Part No.	Description	Remark
2-655-032-11	CUSHION (FOOT) (20 pieces) (for Foot pads of speakers) (SS2000)	
2-682-469-01	FOOT (SW) (4 pieces) (for Foot pads of subwoofer)	
2-893-646-11	FOOT (4 pieces) (for Foot pads of speakers) (SF2000)	
3-087-053-01	+BVTP2.6 (3CR) (for rotation prevention of post) (SF2000)	
3-096-346-01	STAND PIPE (Post) (for speaker stand) (SF2000)	
3-210-806-11	INSTRUCTION MANUAL (ENGLISH)	
3-210-806-21	INSTRUCTION MANUAL (FRENCH) (SF2000: US, Canadian, AEP)	
3-210-806-31	INSTRUCTION MANUAL (SPANISH) (SF2000: US, Canadian, AEP/SS2000)	
3-210-806-41	INSTRUCTION MANUAL (GERMAN, DUTCH, SWEDISH) (SF2000: AEP)	
3-210-806-51	INSTRUCTION MANUAL (ITALIAN, POLISH) (SF2000: AEP)	
3-210-806-61	INSTRUCTION MANUAL (DANISH, FINNISH) (SF2000: AEP)	
3-210-806-71	INSTRUCTION MANUAL (PORTUGUESE) (SF2000: AEP)	
3-210-806-81	INSTRUCTION MANUAL (RUSSIAN) (SF2000: AEP)	
3-210-807-11	INSTRUCTION MANUAL (GREEK) (SF2000: AEP)	
3-210-807-21	INSTRUCTION MANUAL (TURKISH) (SF2000: AEP)	
3-210-807-31	INSTRUCTION MANUAL (HUNGARIAN, CZECH) (SF2000: AEP)	
3-210-807-41	INSTRUCTION MANUAL (SLOVAKIAN) (SF2000: AEP)	
3-211-019-01	SCREW (WASHER) (BLACK) (to install speaker and post) (SF2000)	
7-685-646-79	SCREW +BVTP 3X8 TYPE2 IT-3 (SILVER) (to install post and base) (SF2000)	
9-833-602-12	WIRE KIT (5 pieces) (Speaker cords)	
A-1252-189-A	STAND BASE (M) ASSY (Base) (for speaker stand) (SF2000)	

HOME THEATRE SYSTEM

