

HT-V600DP

SERVICE MANUAL

*US Model
Canadian Model*

Ver 1.0 2004.01

- HT-V600DP is composed of following models.
As for the service manual, it is issued for each component model, then, please refer to them.

COMPONENT MODEL NAME

DVD/VCR RECEIVER HOME THEATER SYSTEM	HT-V600DP
DVD/VCR RECEIVER	AVD-K600P
PACKAGE SPEAKER	SS-VE81P
SUB WOOFER SPEAKER	SS-WMSP81
FRONT/SURROUND+CENTER	SS-CRP76
CENTER SPEAKER	SS-CNP76
FRONT/SURROUND SPEAKER	SS-MSP76

PARTS LIST

<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>
	ACCESSORIES *****	
1-478-247-11	REMOTE CONTROLLER, RM-U600 (INCLUDING BATTERY COVER)	
1-769-108-11	CORD, CONNECTION (VIDEO)	
1-776-263-22	CORD, CONNECTION (AUDIO)	
1-827-243-11	SPEAKER CABLE SET	
4-235-237-01	FOOT (FOR SUB WOOFER SPEAKER)	
4-244-915-01	FOOT (FOR CENTER/SORROUND SPEAKER)	
9-885-054-62	ANTENNA, LOOP (AM)	
9-885-055-50	INSTRUCTION ASSEMBLY	
9-885-055-51	ANTENNA, FM	
9-885-055-53	CABLE, RF NTSC (COAXIAL)	

DVD/VCR RECEIVER HOME THEATER SYSTEM

9-877-541-01
2004A16-1
© 2004.01

Sony Corporation
Home Audio Company
Published by Sony Engineering Corporation

SONY®

