

MDR-XB50BS

SERVICE MANUAL

Ver. 1.0 2016.08

US Model
Canadian Model
AEP Model
UK Model
E Model
Australian Model
Tourist Model

CAUTION

Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type.

警告

本電池如果更換不正確會有爆炸的危險
請依製造商說明書處理用過之電池

- The service policy of this model is Product Exchange.
The following parts are available for service parts of this model.

PARTS LIST

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>
	4-595-527-12	MANUAL, INSTRUCTION (Operating Instructions)	
	4-595-528-11	GUIDE, REFERENCE (ENGLISH, SPANISH, FRENCH) (US, CND)	
	4-595-528-31	GUIDE, REFERENCE (ENGLISH, RUSSIAN, TRADITIONAL CHINESE, KOREAN UKRAINIAN) (E, AUS, JE, RU)	
	4-595-528-41	GUIDE, REFERENCE (ENGLISH, FRENCH, GERMAN, SPANISH, DUTCH, ITALIAN, POLISH, HUNGARIAN) (AEP, UK)	
	4-595-528-51	GUIDE, REFERENCE (PORTUGUESE, GREEK, CZECH, BULGARIAN, SLOVAK, SLOVENIAN, ROMANIAN) (AEP, UK)	

– Continued on next page –

- **Color variations**
(B) Black, (L) Blue, (R) Red
- **Abbreviations**
AUS : Australian, New Zealand models
CND : Canadian model
JE : Tourist model
RU : Russian model

WIRELESS STEREO HEADSET

9-896-307-01

2016H00-1


© 2016.08

Sony Video & Sound Products Inc.

SONY®

MDR-XB50BS

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
1	4-543-903-01	EAR PIECE, LONG (SS) (Long Hybrid silicone rubber earbud: size SS) (1 piece) (Outside: SMOKE BLACK/Inside: RED) (for Black)		5	4-543-915-01	ARC SUPPORTER L (S) (size S: for L-ch) (Shaft: LIGHT SMOKE/Ring: DARK SMOKE) (for Black)	
1	4-543-903-21	EAR PIECE, LONG (SS) (Long Hybrid silicone rubber earbud: size SS) (1 piece) (Outside: TRANSPARENT RED/Inside: RED) (for Red)		5	4-543-915-21	ARC SUPPORTER L (S) (size S: for L-ch) (TRANSPARENT RED) (for Red)	
1	4-543-903-31	EAR PIECE, LONG (SS) (Long Hybrid silicone rubber earbud: size SS) (1 piece) (Outside: TRANSPARENT NAVY/Inside: RED) (for Blue)		5	4-543-915-31	ARC SUPPORTER L (S) (size S: for L-ch) (TRANSPARENT NAVY) (for Blue)	
2	4-543-904-01	EAR PIECE, LONG (S) (Long Hybrid silicone rubber earbud: size S) (1 piece) (Outside: SMOKE BLACK/Inside: ORANGE) (for Black)		6	4-543-916-01	ARC SUPPORTER R (S) (size S: for R-ch) (Shaft: LIGHT SMOKE/Ring: DARK SMOKE) (for Black)	
2	4-543-904-21	EAR PIECE, LONG (S) (Long Hybrid silicone rubber earbud: size S) (1 piece) (Outside: TRANSPARENT RED/Inside: ORANGE) (for Red)		6	4-543-916-21	ARC SUPPORTER R (S) (size S: for R-ch) (TRANSPARENT RED) (for Red)	
2	4-543-904-31	EAR PIECE, LONG (S) (Long Hybrid silicone rubber earbud: size S) (1 piece) (Outside: TRANSPARENT NAVY/Inside: ORANGE) (for Blue)		6	4-543-916-31	ARC SUPPORTER R (S) (size S: for R-ch) (TRANSPARENT NAVY) (for Blue)	
3	4-543-905-01	EAR PIECE, LONG (M) (Long Hybrid silicone rubber earbud: size M) (1 piece) (Outside: SMOKE BLACK/Inside: GREEN) (for Black)		7	4-543-917-01	ARC SUPPORTER L (M) (size M: for L-ch) (Shaft: LIGHT SMOKE/Ring: DARK SMOKE) (for Black)	
3	4-543-905-21	EAR PIECE, LONG (M) (Long Hybrid silicone rubber earbud: size M) (1 piece) (Outside: TRANSPARENT RED/Inside: GREEN) (for Red)		7	4-543-917-21	ARC SUPPORTER L (M) (size M: for L-ch) (TRANSPARENT RED) (for Red)	
3	4-543-905-31	EAR PIECE, LONG (M) (Long Hybrid silicone rubber earbud: size M) (1 piece) (Outside: TRANSPARENT NAVY/Inside: GREEN) (for Blue)		7	4-543-917-31	ARC SUPPORTER L (M) (size M: for L-ch) (TRANSPARENT NAVY) (for Blue)	
4	4-543-906-01	EAR PIECE, LONG (L) (Long Hybrid silicone rubber earbud: size L) (1 piece) (Outside: SMOKE BLACK/Inside: LIGHT BLUE) (for Black)		8	4-543-918-01	ARC SUPPORTER R (M) (size M: for R-ch) (Shaft: LIGHT SMOKE/Ring: DARK SMOKE) (for Black)	
4	4-543-906-21	EAR PIECE, LONG (L) (Long Hybrid silicone rubber earbud: size L) (1 piece) (Outside: TRANSPARENT RED/Inside: LIGHT BLUE) (for Red)		8	4-543-918-21	ARC SUPPORTER R (M) (size M: for R-ch) (TRANSPARENT RED) (for Red)	
4	4-543-906-31	EAR PIECE, LONG (L) (Long Hybrid silicone rubber earbud: size L) (1 piece) (Outside: TRANSPARENT NAVY/Inside: LIGHT BLUE) (for Blue)		8	4-543-918-31	ARC SUPPORTER R (M) (size M: for R-ch) (TRANSPARENT NAVY) (for Blue)	
				9	4-543-919-01	ARC SUPPORTER L (L) (size L: for L-ch) (Shaft: LIGHT SMOKE/Ring: DARK SMOKE) (for Black)	
				9	4-543-919-21	ARC SUPPORTER L (L) (size L: for L-ch) (TRANSPARENT RED) (for Red)	
				9	4-543-919-31	ARC SUPPORTER L (L) (size L: for L-ch) (TRANSPARENT NAVY) (for Blue)	
				10	4-543-920-01	ARC SUPPORTER R (L) (size L: for R-ch) (Shaft: LIGHT SMOKE/Ring: DARK SMOKE) (for Black)	
				10	4-543-920-21	ARC SUPPORTER R (L) (size L: for R-ch) (TRANSPARENT RED) (for Red)	
				10	4-543-920-31	ARC SUPPORTER R (L) (size L: for R-ch) (TRANSPARENT NAVY) (for Blue)	
				11	9-885-197-34	CABLE, MICRO (USB) (approx. 50 cm)	



MEMO

