

# WI-1000X

## SERVICE MANUAL

Ver. 1.0 2017.08

*US Model*  
*Canadian Model*  
*AEP Model*  
*UK Model*  
*E Model*  
*Australian Model*  
*Chinese Model*  
*Tourist Model*

### CAUTION

Danger of explosion if battery is incorrectly replaced.  
Replace only with the same or equivalent type.

### 注意

如果电池更换不当会有爆炸危险  
只能用同样类型或等效类型的电池来更换

### 警告

本電池如果更換不正確會有爆炸的危險  
請依製造商說明書處理用過之電池

- The service policy of this model is Product Exchange.  
The following parts are available for service parts of this model.

### PARTS LIST

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>
	4-696-993-12	MANUAL, INSTRUCTION (Operating Instructions)	(Except CH)
	4-696-993-22	MANUAL, INSTRUCTION (Operating Instructions)	(CH)
	4-696-994-11	GUIDE, REFERENCE (ENGLISH, SPANISH, FRENCH) (US, CND, LA)	
	4-696-994-22	GUIDE, REFERENCE (SIMPLIFIED CHINESE)	(CH)
	4-696-994-32	GUIDE, REFERENCE (ENGLISH, RUSSIAN, TRADITIONAL CHINESE, KOREAN)	(E, AUS, JE, RU)
	4-696-994-41	GUIDE, REFERENCE (ENGLISH, FRENCH, GERMAN, SPANISH, DUTCH, ITALIAN, POLISH, HUNGARIAN) (AEP, UK)	
	4-696-994-51	GUIDE, REFERENCE (PORTUGUESE, GREEK, CZECH, BULGARIAN, SLOVAK, SLOVENIAN, ROMANIAN) (AEP, UK)	

– Continued on next page –

### • Abbreviations

AEP : European area, East European area, CIS area (Moldova) models  
AUS : Australian model  
CH : Chinese model  
CND : Canadian model  
JE : Tourist model  
LA : Latin American model  
RU : Russian (CIS area: Except for Moldova) model

### • Color variations

(B) Black, (N) Champagne Gold

## WIRELESS NOISE CANCELING STEREO HEADSET

9-896-424-01


2017H00-1

© 2017.08

Sony Video & Sound Products Inc.

# SONY®

Ref. No.	Part No.	Description	Remark
1	3-275-257-01	PIECE (SS), EAR (Hybrid silicone rubber earbud: size SS) (1 piece) (Outside: BLACK/Inside: RED) (for BLACK)	
2	3-275-255-02	PIECE (S), EAR (Hybrid silicone rubber earbud: size S) (1 piece) (Outside: BLACK/Inside: ORANGE) (for BLACK)	
3	3-275-254-01	PIECE (M), EAR (Hybrid silicone rubber earbud: size M) (1 piece) (Outside: BLACK/Inside: GREEN) (for BLACK)	
4	3-275-256-02	PIECE (L), EAR (Hybrid silicone rubber earbud: size L) (1 piece) (Outside: BLACK/Inside: LIGHT BLUE) (for BLACK)	
5	4-575-658-71	PIECE (SS), EAR (Hybrid silicone rubber earbud: size SS) (1 piece) (BEIGE: 1 line) (for Champagne Gold)	
6	4-575-656-71	PIECE (S), EAR (Hybrid silicone rubber earbud: size S) (1 piece) (BEIGE: 2 lines) (for Champagne Gold)	
7	4-575-655-71	PIECE (M), EAR (Hybrid silicone rubber earbud: size M) (1 piece) (BEIGE: 3 lines) (for Champagne Gold)	
8	4-575-657-71	PIECE (L), EAR (Hybrid silicone rubber earbud: size L) (1 piece) (BEIGE: 4 lines) (for Champagne Gold)	
9	4-591-876-01	EAR PIECE (S), TRIPLE COMFORT (Triple-comfort earbud: size S) (1 piece) (Outside: BLACK/Inside: ORANGE)	
10	4-591-875-01	EAR PIECE (M), TRIPLE COMFORT (Triple-comfort earbud: size M) (1 piece) (Outside: BLACK/Inside: GREEN)	
11	4-591-877-01	EAR PIECE (L), TRIPLE COMFORT (Triple-comfort earbud: size L) (1 piece) (Outside: BLACK/Inside: LIGHT BLUE)	
12	1-912-190-61	CABLE (WITH PLUG) BLK1 (Dedicated headphone cable (approx. 1 m)) (BLACK) (for Black)	
12	1-912-190-71	CABLE (WITH PLUG) GLD1 (Dedicated Headphone cable (approx. 1 m)) (GOLD) (for Champagne Gold)	
13	4-697-128-01	CARRYING, POUCH (for Black)	
13	4-697-128-11	CARRYING, POUCH (for Champagne Gold)	
14	1-843-730-11	ADAPTOR, PLUG (IN FLIGHT USE) (Plug adaptor for airplane)	
15	1-848-682-11	CABLE, CONNECTION (USB) (Micro-USB cable (approx. 50 cm))	



MEMO

