

WI-SP600N

SERVICE MANUAL

Ver. 1.0 2018.03

CAUTION

Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type.

注意

如果电池更换不当会有爆炸危险
只能用同样类型或等效类型的电池来更换

警 告

本電池如果更換不正確會有爆炸的危險
請依製造商說明書處理用過之電池

US Model
Canadian Model
AEP Model
UK Model
E Model
Australian Model
Chinese Model
Tourist Model

- The service policy of this model is Product Exchange.
The following parts are available for service parts of this model.

PARTS LIST

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>
	4-730-311-11	MANUAL, INSTRUCTION (Operating Instructions)	(Except CH)
	4-730-311-21	MANUAL, INSTRUCTION (Operating Instructions)	(CH)
	4-730-312-12	GUIDE, REFERENCE (ENGLISH, SPANISH, FRENCH) (US, CND, LA)	
	4-730-312-21	GUIDE, REFERENCE (SIMPLIFIED CHINESE)	(CH)
	4-730-312-32	GUIDE, REFERENCE (ENGLISH, RUSSIAN, UKRAINIAN, TRADITIONAL CHINESE, KOREAN)	(E, AUS, JE, RU, IND)
	4-730-312-42	GUIDE, REFERENCE (ENGLISH, FRENCH, GERMAN, SPANISH, DUTCH, ITALIAN, POLISH, HUNGARIAN) (AEP, UK)	
	4-730-312-51	GUIDE, REFERENCE (PORTUGUESE, GREEK, CZECH, BULGARIAN, SLOVAK, SLOVENIAN, ROMANIAN) (AEP, UK)	

– Continued on next page –

• Color variations

Except IND : (B) Black, (W) White, (Y) Yellow, (P) Pink
IND : (B) Black

• Abbreviations

AEP : European area, East European area, CIS area (Moldova), Middle East area (Israel) models
AUS : Australian (Oceania area) model
CH : Chinese model
CND : Canadian model
IND : Indian model
JE : Tourist model
LA : Latin American model
RU : CIS area (Except for Moldova) model

WIRELESS NOISE CANCELING STEREO HEADSET

9-896-507-01

2018C00-1

© 2018.03


Sony Video & Sound Products Inc.

SONY®

WI-SP600N

Ref. No.	Part No.	Description	Remark
1	4-543-903-01	EAR PIECE, LONG (SS) (1 piece) (Long Hybrid silicone rubber earbud: size SS) (Outside: SMOKE BLACK/Inside: RED) (for Black)	
1	4-543-903-11	EAR PIECE, LONG (SS) (1 piece) (Long Hybrid silicone rubber earbud: size SS) (Outside: MILKEY WHITE/Inside: RED) (for White)	
1	4-543-903-71	EAR PIECE, LONG (SS) (1 piece) (Long Hybrid silicone rubber earbud: size SS) (Outside: TRANSPARENT LIGHT YELLOW/ Inside: RED) (for Yellow)	
1	4-543-903-81	EAR PIECE, LONG (SS) (1 piece) (Long Hybrid silicone rubber earbud: size SS) (Outside: TRANSPARENT MISTYROSE/ Inside: RED) (for Pink)	
2	4-543-904-01	EAR PIECE, LONG (S) (1 piece) (Long Hybrid silicone rubber earbud: size S) (Outside: SMOKE BLACK/Inside: ORANGE) (for Black)	
2	4-543-904-11	EAR PIECE, LONG (S) (1 piece) (Long Hybrid silicone rubber earbud: size S) (Outside: MILKEY WHITE/Inside: ORANGE) (for White)	
2	4-543-904-71	EAR PIECE, LONG (S) (1 piece) (Long Hybrid silicone rubber earbud: size S) (Outside: TRANSPARENT LIGHT YELLOW/ Inside: ORANGE) (for Yellow)	
2	4-543-904-81	EAR PIECE, LONG (S) (1 piece) (Long Hybrid silicone rubber earbud: size S) (Outside: TRANSPARENT MISTYROSE/ Inside: ORANGE) (for Pink)	
3	4-543-905-01	EAR PIECE, LONG (M) (1 piece) (Long Hybrid silicone rubber earbud: size M) (Outside: SMOKE BLACK/Inside: GREEN) (for Black)	
3	4-543-905-11	EAR PIECE, LONG (M) (1 piece) (Long Hybrid silicone rubber earbud: size M) (Outside: MILKEY WHITE/Inside: GREEN) (for White)	
3	4-543-905-71	EAR PIECE, LONG (M) (1 piece) (Long Hybrid silicone rubber earbud: size M) (Outside: TRANSPARENT LIGHT YELLOW/ Inside: GREEN) (for Yellow)	
3	4-543-905-81	EAR PIECE, LONG (M) (1 piece) (Long Hybrid silicone rubber earbud: size M) (Outside: TRANSPARENT MISTYROSE/ Inside: GREEN) (for Pink)	
4	4-543-906-01	EAR PIECE, LONG (L) (1 piece) (Long Hybrid silicone rubber earbud: size L) (Outside: SMOKE BLACK/Inside: LIGHT BLUE) (for Black)	
4	4-543-906-11	EAR PIECE, LONG (L) (1 piece) (Long Hybrid silicone rubber earbud: size L) (Outside: MILKEY WHITE/Inside: LIGHT BLUE) (for White)	
4	4-543-906-71	EAR PIECE, LONG (L) (1 piece) (Long Hybrid silicone rubber earbud: size L) (Outside: TRANSPARENT LIGHT YELLOW/ Inside: LIGHT BLUE) (for Yellow)	
4	4-543-906-81	EAR PIECE, LONG (L) (1 piece) (Long Hybrid silicone rubber earbud: size L) (Outside: TRANSPARENT MISTYROSE/ Inside: LIGHT BLUE) (for Pink)	

Ref. No.	Part No.	Description	Remark
5	4-726-291-01	ARC SUPPORTER L (M) (size M: for L-ch) (LIGHT SMOKE) (for Black)	
5	4-726-291-11	ARC SUPPORTER L (M) (size M: for L-ch) (MILKEY WHITE) (for White)	
5	4-726-291-21	ARC SUPPORTER L (M) (size M: for L-ch) (TRANSPARENT YELLOW) (for Yellow)	
5	4-726-291-31	ARC SUPPORTER L (M) (size M: for L-ch) (TRANSPARENT PINK) (for Pink)	
6	4-726-292-01	ARC SUPPORTER R (M) (size M: for R-ch) (LIGHT SMOKE) (for Black)	
6	4-726-292-11	ARC SUPPORTER R (M) (size M: for R-ch) (MILKEY WHITE) (for White)	
6	4-726-292-21	ARC SUPPORTER R (M) (size M: for R-ch) (TRANSPARENT YELLOW) (for Yellow)	
6	4-726-292-31	ARC SUPPORTER R (M) (size M: for R-ch) (TRANSPARENT PINK) (for Pink)	
7	4-726-293-01	ARC SUPPORTER L (L) (size L: for L-ch) (LIGHT SMOKE) (for Black)	
7	4-726-293-11	ARC SUPPORTER L (L) (size L: for L-ch) (MILKEY WHITE) (for White)	
7	4-726-293-21	ARC SUPPORTER L (L) (size L: for L-ch) (TRANSPARENT YELLOW) (for Yellow)	
7	4-726-293-31	ARC SUPPORTER L (L) (size L: for L-ch) (TRANSPARENT PINK) (for Pink)	
8	4-726-294-01	ARC SUPPORTER R (L) (size L: for R-ch) (LIGHT SMOKE) (for Black)	
8	4-726-294-11	ARC SUPPORTER R (L) (size L: for R-ch) (MILKEY WHITE) (for White)	
8	4-726-294-21	ARC SUPPORTER R (L) (size L: for R-ch) (TRANSPARENT YELLOW) (for Yellow)	
8	4-726-294-31	ARC SUPPORTER R (L) (size L: for R-ch) (TRANSPARENT PINK) (for Pink)	
9	1-848-682-21	CABLE, CONNECTION (USB) (Micro-USB cable (approx. 50 cm))	



MEMO

