





MT 93
TIMER
COMPLETE
INCLUDES MT 87, 86
84, 83, 82, 62 & 94



MODEL 9A-BTM Series

Key Number	Part Number	Number Per Unit	Description
			NOTE: Key#'s BP are old, ie; BP47 = MT83, BP16 = MT90
MT5	A9-Z1207	1	Crumb Tray (including Handle) BTM2
	A9-Z1208	1	Crumb Tray (including Handle) BTM4
MT9	A9-04-TO-0025		Side Baffle (not available)
MT11	A9-04-TO-0133		Terminal Box Cover
MT15			Bottom Panel (not available)
MT20			Bread Support <i>(not shown)</i> (not available)
MT21	A9-30-TO-0002		120V Element for 120V, 230V Bread Toaster (not available)
MT21A	A9-30-TO-0046		208V Element for Bread Toaster (not available)
MT21B	A9-40-TO-0045		Bun Element for 120V, 208V, or 230V (not available)
MT22	A9-40-TO-0004	4	Plastic Leg
MT22A	2C-08-07-0114		Leg Screw <i>(not shown)</i>
MT26	A9-04-TO-0035		Guide Rod (not available)
MT28	2P-09-TO-0005		Bumper Spring
MT29	2A-09-TO-0008		Oilless Bushing
MT32A	A9-70-TO-0008		Guard Wire Assembly
MT34B	2R-51-TO-0031		Winding Handle W/Set Screw
MT34C	2P-09-TO-0003		Winding Handle Spring
MT35	2R-51-TO-0032		Crumb Tray Handle <i>(W/2 Screws)</i>
MT37			Element Clamp Screw (not available)
MT38	A9-70-TO-0002		Element Clamp <i>(not shown)</i>
MT40	A9-04-TO-0044		Flat Spring
MT42	2A-05-TO-0007		Porcelain Bushing for Terminal Block & Side Spacer
MT42A	A9-50-TO-0006		Plastic Terminal Box or Board W/Studs <i>(not shown)</i>
MT62	2C-08-07-0308		Spring Lock
MT70	2R-09-TO-0001		Time Adjustor Knob
MT77	A9-30-TO-0001		Wedge & Element Holder W/Wires (not available)
MT79	A9-04-TO-0013		Jumper
MT80			Nut, Washer and Cup Washer (not available)
MT81	A9-04-TO-0010		Heater Guard
MT82	A9-50-TO-0021		4 Contacts on Fiberglass Shunt & Contact (not available)
MT83	A9-30-TO-0075		Heater & Bimetal Strip for 120V, 230V Bread Toaster (not available)
	A9-30-TO-0029		Heater & Bimetal Strip for 208V Bread Toaster (not available)
MT83A	A9-30-TO-0057		Bun Heater & Bimetal Strip for Toaster
MT84	A9-50-TO-0022		Main Bracket W/O #MT83, 87, 86, and 82
MT85	2A-09-TO-0009		Timer Shaft (not available)
MT86	A9-04-TO-0044		Flat Friction Spring
MT87	A9-40-TO-0002		Reset Lever
MT88	A9-40-TO-0006		Top Main Switch Complete
MT88A			Bracket, 2 Screws, Spring for Switch <i>(not shown)</i> (not available)
MT89	A9-30-TO-0030		Winding Mechanism Trip Catch, Spring, Bushing
MT90	2P-09-TO-0004		Pop Up Spring
MT91	2P-09-TO-0003		Coil Spring for Trip Catch
MT92	A9-40-TO-0005		Basket & Bread Holders W/Oilless Bushing-No Switch
MT93	A9-30-TO-0035		Timer, Including MT82, 83, 86, 87, and 94 <i>(120V, 230V)</i> (not available)
	A9-BT0002		Timer, Including MT82, 83, 86, 87, and 94 <i>(208V)</i> (not available)
MT94	2P-09-TO-0010		Coil Spring for Trip Catch
MT95			Ceramic Insulator (not available)
	2E-05-07-0050		Cordset: 12/3 Nema #5-20P, 120V (4 Slice)
	2E-05-07-0052		Cordset: 14/3 Nema #6-15P, 208/230V (4 Slice & 2 Slice)
	2E-05-07-0005		Cordset: 14/3 Nema #5-15P, 120V (2 Slice)

IMPORTANT: WHEN ORDERING, SPECIFY VOLTAGE OR TYPE GAS DESIRED
INCLUDE MODEL AND SERIAL NUMBER

PAGE 1
OF 1

Some items are included for illustrative purposes only and in certain instances may not be available.



Star Manufacturing International, Inc.