



MODEL: CRT14E CONTACT / RADIANT TOASTER

SK2913, Rev. A, 7/30/2015

2M-Z20664; Contact & Radiant Dual Toaster



PARTS LIST

October 19, 2015, Rev. B

Model: CRT14EM & CRT14ES Contact / Radiant Toaster				
Fig No.	Part Number	Quantity	Description	Application
1	2A-Z20478	2	SUPPORT-HOUSING 1.125"L	
2	2C-1488	12	SCREW 6-32X3/8 RHP STL NP	
3	2A-Z20477	2	BUSHING, OUTER	
4	HC-CT0043	1	PLATEN COVER ASSEMBLY	
5	2R-Y6762	1	HANDLE-DIMCO GRAY 190	
6	2A-Z17727	2	SPACER, 5/8"OD X 0.266"ID	
7	HC-Z17713	1	RETAINER, PTFE SHEET	
8	2A-Z17712	3	THUMBSCREW 8-32 X .375	
9	2C-6517	3	NUT 1/4-20 HEX STL NP	
10	HC-Z17724	1	THERMOPROBE BRKT	
11	2C-1512	11	SCREW 10-24X3/8 RHP STL	
12	HC-Z17711	1	ELEMENT COVER	
13	2E-Z17719	1	TYPE K PROBE	
14	2C-Z3350	1	HALF CLAMP .188 D STL ZP	
15	2N-Z17710	1	ELEMENT, METAL 2300W 240V	
16	2F-Z17708	1	13" TOP CASTING	
17	2A-Z18504	1	SPACER, 3/8IN X 1/4IN	
18	2C-Y7595	1	BOLT 1/4-20X1/2 THS STL	
19	2H-Z18588	1	PTFE SHEET 0.003 TK SING	
20	2A-CT0011	2	ADJUSTMENT KNOB ASY	
21	2H-Z17747	2	WASHER, 3/8IN OD TPTFE	
22	2C-20201-04	2	WSHR FLT 3/8 USS PLTD	
23	2C-Z19112	2	COTTER PIN, 7/64 X 3/4	
24	2C-Z6929	46	10-24 KEPS NUT S.S.	
25	2C-1810	24	WASHER 3/16 BURR STL NP	
26	HC-CT0012	1	LEFT ADJUSTMENT BRKT ASY	
27	2V-Z17744	1	PLATEN SUPPORT	
28	2K-Z17715	2	BUSHING, INNER	
29	HC-CT0014	1	PLATEN LATCH ASY	
30	HC-CT0013	1	RIGHT ADJUSTMENT BRKT ASY	
31	HC-Z20565	1	COVER, REAR	
32	2C-6349	22	SCREW #8X3/8 B THP STL NP	
33	HC-CT0039	1	REAR PANEL ASSEMBLY	
34	2C-Z10075	1	SCREW-1/4-20X3/8 SS THS	
35	HC-Z17737	1	PLATEN SUPPORT BRKT	
36	HA-112261	4	BEARING ASSY, 5/16 PTFE	
37	2K-Y6764	1	BUSHING - STRAIN RELIEF	
38	2A-202902	2	SHAFT, T714 DRIVE	CRT14EM
	2A-Z20476	1	BELT DRIVE SHAFT ASSY	CRT14ES
39	HC-Z16924	2	SHAFT ACCESS COVER PLATE	
40	2P-200645	1	SPROCKET, 25B17 X 5/16	
41	2P-200648	2	SPROCKET, 25B32 X 5/16	

2M-Z20664; Contact & Radiant Dual Toaster

PARTS LIST

October 19, 2015, Rev. B

Model: CRT14EM & CRT14ES Contact / Radiant Toaster				
Fig No.	Part Number	Quantity	Description	Application
42	2P-Z20710	1	CHAIN #25 15" 60 LINKS	
43	2E-Z17514	2	SENSOR, SPEED	
44	HC-Z20563	1	BRACKET, SPEED SENSOR	
45	2U-Z9657	1	MOTOR,11RPM-CW,NEW STYLE	
46	2M-Z18512	1	LABEL, LOCK SYMBOL	
47	2M-Z18513	1	LABEL, UNLOCK SYMBOL	
48	2R-Z17729	1	KNOB, 1-1/4 X 5/8 X 1/2	
49	HC-Z20559	1	PANEL, RIGHT SIDE	
50	HC-Z20561	1	ELEMENT RETAINER	
51	HC-Z20564	2	ELEMENT SUPPORT	
52	2N-209130	4	ELEMENT, METAL 208V 800W	208V
	2N-209160		ELEMENT, METAL 240V 800W	240V
53	2E-Z10406	1	TERMINAL BLOCK 4 POS	
54	2U-200592	2	QCSE POWER BOARD	
55	2R-Z18201	4	FOOT 1.69X1 SIL 1/4 20	
56	2E-Z20554	2	FUSEHOLDER, 15A CLASS G	
57	2E-Z8405	4	FUSE,15A CLASS G	
58	2E-200566	1	SWTCH,RSET,0796-190F TRPS	
59	2U-200561	1	MOTOR, FAN 240V 23BTM	
60	HC-Z20560	1	MOTOR HOUSING COVER	
61	2R-200562	1	FAN GUARD FOR MUFFIN FAN	
62	2C-Z5883	4	10-24 X 1/2 FZA SCREW	
63	HC-Z20351	1	SOFTWARE, CRT14E	
64	2M-Z20369	1	LABELS, CRT14E	
65	2J-Z17717	1	ELECTRONIC CONTROL SPEC	
66	2M-Z20369	1	LABELS, CRT14E	
67	HC-Z20566	1	TOAST SLIDE	
68	HC-Z20569	2	CRUMB TRAY	
69	HC-Z20557	1	BELT GUARD	
70	2M-Z17735	1	LABEL, HEEL	
71	2M-Z17750	1	LABEL, CROWN	
72	HC-CT0040	1	BELT GUARD ASSEMBLY	
73	2P-Z18587	4	BEARING SPRING 2IN	
74	2P-200700	4	BRG SPRING LOADED	
75	2A-202905	2	SHAFT, 214HX IDLER	CRT14EM
		1		CRT14ES
	2A-202902	2	SHAFT, T714 DRIVE	CRT14ES
76	2K-200464	4	BUSHING, WIRE RING 7/8"	
77	2U-Z9658	1	MOTOR AC 11 RPM CCW	
78	2P-Z20735	1	CHAIN #25 26.5" 106 LINKS	
79	2P-200646	1	SPROCKET, 25B20 X 5/16	
80	HC-Z20562	1	BRACKET, SPEED SENSOR	

2M-Z20664; Contact & Radiant Dual Toaster

PARTS LIST

October 19, 2015, Rev. B

Model: CRT14EM & CRT14ES Contact / Radiant Toaster				
Fig No.	Part Number	Quantity	Description	Application
81	HC-Z20558	1	PANEL, LEFT SIDE	
82	2M-Z18258	2	LABEL, SCALE	
83	2T-30401-30	1	STAT FXD 550 DEG OPEN	
NI	HM-160004	2	BELT, CONVEYOR 14" X 39", PLUS (3) LINKS	CRT14EM
		1		CRT14ES
NI	2B-200603	6	BELT LINK SPACECLIP	CRT14EM
		3		CRT14ES
NI	2E-200374	1	CORD SET 12/3 6-30 T714 8	
NI	2I-Z18519	1	SILICONE BELT SEGMENT 40"	CRT14ES