

OPERATOR'S MANUAL
 HOLMAN CONVEYOR TOASTERS
MODELS T914, S914

PARTS LIST

<u>PART#</u>	<u>QTY</u>	<u>PAGE#</u>	<u>DESCRIPTION</u>
200538	2	6	Infinity Switch
200702	2	6	Knob, Infinity Switch
118040	1	6	Variable Speed Control
200703	1	6	Knob, Variable Speed Control
197019	4	7	Heater Tube, 208V
197022	4	7	Heater Tube, 220V
197027	4	7	Heater Tube, 240V
200566	1	5	Heat Limit Switch, 190F
160006	1	4	Conveyor Belt
400833	4	7	Heater Tube Retainers
150000	1	6	Drive Chain
100905	1	4	Idler Shaft
100902	1	4	Drive Shaft
112261	2	6	Bushing 5/16 I.D., Rear
200693	2	6	Bushing, Idler Shaft
200509	1	9	Drive Motor 208-240V
200521	1	9	Drive Motor 220V 50 Hz
200561	1	8	Fan Motor, 208/240V
200562	1	Not Shown	Fan Grill
115388	2	6	Terminal Strip 6 Poss.
115386	1	7	Terminal Strip 9 Poss.
115502	4	7	Copper Jumpers, 3 Poss.
115501	4	7	Copper Jumpers, 2 Poss.
100529	1	4	Crumb Tray
140028	1	14	Cord/Plug Set
100314	1	8	Control Box Cover
401022	1	2	Toast Chute (T914)
100603	1	1A	Toast Chute (S914)
200751	1	1A	Key Lock (S914)
100876	1	1A	Key Lock Cover (S914)
100935	1	1A	Rod, Toast Chute (S914)
200280	4	1A	Cotter Pin (S914)
200712	4	1A	Leg