



SOME ITEMS ARE INCLUDED FOR ILLUSTRATIVE PURPOSES ONLY AND IN CERTAIN INSTANCES MAY NOT BE AVAILABLE

MODEL: T2, T4, BT4, CT4 POP-UP TOASTERS



SK2396 Rev. C 2/05/2013

# PARTS LIST

July 9, 2012, Rev. -

MODELS; T2, T4, CT4, BT4 SOLID STATE SLOT TOASTER				
Fig No	Part No	Qty	Description	Application
1	A8-35404	1	ASSY, COVER & INSULATION	T2
	A8-39295		ASSY, TOP COVER & INSUL	T4
	A8-39296			BT4
	A8-39865			CT4
2	A8-32523	1	SPACER, STRINGER SUPPORT	BT4, CT4, T4
	A8-34455			BT4, CT4, T4
3	A8-32541	1	SUPPORT, BREAD LEFT HAND	T2
		2		BT4, CT4, T4
4	A8-32540	2/4	ASSY, SUPPORT ELEVATOR	
5	A8-32542	1	SUPPORT, BREAD RIGHT HAND	T2
		2		BT4, CT4, T4
6	A8-7606061	1	ASSY, BRACKET & CYLINDER	T2
		2		BT4, CT4, T4
7	2A-7002277	4	BUSHING	T2
		8		BT4, CT4, T4
8	2A-7002276	2	SHAFT, VERTICAL, 304 S/S	T2
		4		BT4, CT4, T4
9	A8-7606063	1	ASSY, PISTON	T2
		2		BT4, CT4, T4
10	A8-7606065	1	ASSY, SOLENOID & LATCH	
		2		BT4, CT4, T4
11	2E-3003505	2	SOLENOID, TOASTER	BT4, CT4
12	A8-7002282	1	BRACKET, SOLENOID MTG	T2
		2		BT4, CT4, T4
13	A8-33310	1	ASSY, CHASIS TOP	BT4, CT4, T4
14	2E-47823	2	SWITCH, 20 AMP	T2
		4		BT4, CT4, T4
15	A8-7001568	1	BRACKET, SWITCH	T2
		2		BT4, CT4, T4
16	A8-35368	1	PLATE, TOASTER FRONT 2	T2
	A8-39249		PLATE, TOASTER FRONT 4	BT4, CT4, T4
17	2R-39382	1	KNOB TOASTR CTRL (POP UP)	T2
		2		BT4, CT4, T4
18	2J-35736	1	ASSY, TIMER CTRL 120/208/	CT4
		2		BT4
	2J-7604901	2	ASSY, TIMER CONT 104V	T4-208V
	2J-7605984	1	ASSY, TIMER CONT 120V	CT4-240V, T2-240V
	2E-7606512	1	TIME CONT 120V	CT4-120V, T2-120V
2E-7606512	2	TIME CONT 120V	T4-120V	
19	A8-7604286	1	WLDMT, ENCLOSURE CTRL	BT4, CT4, T4
	2E-36025		ENCLOSURE, CONTROL	T2

2M-Z11894 Slot-Toaster T2, T4, CT4, BT4



# PARTS LIST

July 9, 2012, Rev. -

MODELS; T2, T4, CT4, BT4 SOLID STATE SLOT TOASTER				
Fig No	Part No	Qty	Description	Application
20	<a href="#">2M-52-0374</a>	1	LABEL CONTROL PNL 4 SL TM	BT4, CT4, T4
	<a href="#">2M-52-0375</a>		LABEL CONTROL PNL 2SL TM	T2
21	<a href="#">2R-3101757</a>	1	KNOB, OPERATING	T2
		2		BT4, CT4, T4
22	<a href="#">2W-33309</a>	1	CHASIS BOTTOM & BACK, ASY	BT4, CT4, T4
	<a href="#">2W-35327</a>		ASSY, CHASSIS BOTTOM AND BACK	T2
23	<a href="#">2L-3102164</a>	2	BASE, TOASTER	BT4, CT4, T4
24	<a href="#">2A-K1DS268</a>	4	PAD, RUBBER FOOT, ADHSV	BT4, CT4, T4, T2
25	<a href="#">A8-35400</a>	1	TRAY, CRUMB	T2
	<a href="#">A8-7001948</a>			BT4, CT4, T4
26	<a href="#">2E-32323</a>	1	BOARD, TERMINAL, TU95101	BT4, CT4, T4
	<a href="#">2E-35340</a>		BOARD, TERMINAL	T2
27	<a href="#">A8-32524</a>	1	COVER, REAR ELECTRICAL	BT4, CT4, T4
	<a href="#">A8-35338</a>			T2
28	<a href="#">A8-32527</a>	2	ASSY, ROD AND GUARD	CT4
		4		BT4, T2
		8		T4
29	<a href="#">2N-3001804</a>	8	ELEMENT, FOIL HEATING	T4-208V
	<a href="#">2N-3001805</a>	4		CT4-120V, T2-120V
		8		T4-120V
	<a href="#">2N-3001806</a>	4		CT4-240V, T2-240V
		8		T4-208/240V
	<a href="#">2N-3001878</a>	2		CT4-120/240V
30	<a href="#">A8-36853</a>	2	PLATE, ELEMENT REPLACEMNT	CT4
		4		BT4
31	<a href="#">A8-35229</a>	1	SHIELD, HEAT FRONT	T2
	<a href="#">A8-36854</a>			BT4
	<a href="#">A8-39863</a>		SHIELD, HEAT FRONT HYBRID	CT4
32	<a href="#">A8-35280</a>	1	SHIELD, HEAT REAR	T2
	<a href="#">A8-36855</a>			BT4
	<a href="#">A8-39864</a>		SHIELD, HEAT REAR HYBRID	CT4
33	<a href="#">A8-7606066</a>	1	ASSY, ACTUATOR	T2
		2		BT4, CT4, T4
NI	<a href="#">2C-3101206</a>	1	CLAMP, WIRE	BT4, CT4, T4, T2
NI	<a href="#">2C-3B82D8735</a>	1	CONNECTOR, STRAIGHT 3/8"	BT4, CT4, T4, T2
NI	<a href="#">2C-57386</a>	1	PIN, COTTER, 1/8X1-3/4,	T2
NI	<a href="#">2C-57386</a>	2	PIN, COTTER, 1/8X1-3/4,	BT4, CT4, T4
NI	<a href="#">2E-1D3S5</a>	1	CORDSET (6-15P) 15A-250V	BT4-240V, CT4-240V,
NI	<a href="#">2E-31785</a>	1	ASSY, CORDSET	BT4-120V
NI	<a href="#">2E-41486</a>	1	CORDSET, (6-20P) 250V 20A	T4-208V
NI	<a href="#">2P-3103246</a>	1	SPRING, EXTENSION	T2
NI	<a href="#">2P-3103246</a>	2	SPRING, EXTENSION	BT4, CT4, T4
NI	<a href="#">A8-41780</a>	1	ASSY, CORDSET 125V15A	T2

2M-Z11894 Slot-Toaster T2, T4, CT4, BT4

