


Some items are included for illustrative purposes only and in certain instances may not be available.



SK2821, Rev. - 12/10/14

Model: TG14, 14" Sandwich Grill

2M-Z19329 Toastmaster TG14 Sandwich Grills

PARTS LIST

December 10, 2014, Rev. -

14' TWO SIDED GRILLS

Model: TG14 Series Sandwich Grill				
Fig. No.	Part Number	Quantity	Description	Application
1	2C-40637	6	NUT 1/4-20 ACORN CAP MS S	
2	2C-Z2992	6	BOLT 1/4-20X1 PHP STL NP	
3	2B-Z2987	2	ARM - 14"	TG14-IS, TG14IG
	2B-Z3336		14" GR14SPT ARM	TG14-AG, TG14-AS
4	2C-Z3200	2	PIN - TOP HOUSING	
5	2E-Z2898	1	CONDUIT ASSY. - PTFE	
6	2C-Z3917	2	RIVET, POP, .188 (AD66BS)	
7	2C-Z3780	2	RETAINER, CONDUIT	
8	2A-Z3827	1	PLATE,STAMPING - CONDUIT	
9	2C-Z5883	8	10-24 X 1/2 FZA SCREW	
10	D9-Z4849	1	HOUSING - TOP - 14"	
11	2V-Z2989	1	HANDLE- 14"	
12	B9-04-WB-0046	1	CLAMP WIRE SUPPORT	
13	2C-Y1451	2	RIVET 1/8 x .337 MORISON	
14	D9-Z13012	1	WIRE MOUNT	
15	2C-Z2893	12	NUT 10-24 HEX STL ZP	
16	D9-Z13099	2	BRACKET, INSLUATION	
17	D9-Z2075	1	TOP ELEMENT/INS. PLATE/14	
18	2N-Z1980	1	ELEMENT,800WATT 120V-14T	120V
	2N-Z2391		ELEMENT 1800WATT 240V-14T	240V
19	2C-08-07-0285	8	SCREW 10-24X3/4X3/8 TYPE	
20	2F-Z1946	1	CASTING,GR. TOP, ALUM.-14"	TG14-AG
	2F-Z1948		CASTING, SM.TOP,IRON-14	TG14-IS
	2F-Z1950		CASTING,GR.TOP, IRON-14"	TG14-IG
	2F-Z7786		TOP CASTING, SM, AL.-14"	TG14-AS
21	2F-Z11953	1	BOT. CAST.SMOOTH 14 ALUM.	TG14-AS
	2F-Z11954		BOT. CAST GROOVED 14 ALUM	TG14-AG
	2F-Z1949		CASTING,SM. BOT.,IRON-14"	TG14-IS
	2F-Z1951		CASTING, GR. BOT.,IRON-14"	TG14-IG
22	2T-6447	1	THERMOSTAT 118V-236V	
23	2N-Z1981	1	ELEMENT,1000WATT 120V-14B	120V
	2N-Z2392		ELEMENT 1800WATT 240V-14B	240V
24	D9-Z13338	1	ELEMENT & INSULATION PLT	
25	D9-Z2888	2	INSULATION - 14"	
26	D9-Z12885	2	INSULATION HOLD DOWN,	
27	2K-Y3240	1	BUSHING - STRAIN RELIEF	120V
	2K-Y6764		BUSHING - STRAIN RELIEF	240V
28	2A-Z11501	4	FOOT 1" SOLID RUBBER	TG14-AG, TG14-AS
29	2C-6349	8	SCREW #8X3/8 B THP STL NP	
30	D9-GR0525	1	BASE/GRS CAB/CORD PLT ASM	
31	2C-1522	4	SCREW 1/4-20X.5 STL R.H.	
32	D9-Z3071	4	BRACKET - HANDLE	
33	2V-Z3072	2	HANDLE-SIDE	

2M-Z19329 Toastmaster TG14 Sandwich Grills

Model: TG14 Series Sandwich Grill

Fig. No.	Part Number	Quantity	Description	Application
34	2C-1512	8	SCREW 10-24X3/8 RHP STL	
35	2C-08-07-0262	4	WASHER, SS 1/4 INT-LOCK	
36	2C-Z2593	4	10-24x1 1/2 SL HX/W NP	
37	2R-Z1951	1	CASTING, GR. BOT., IRON-14"	TG14-IG, TG14-IS
	2R-Z2897		COUNTER BALANCE/14"/ALUM.	TG14-AG, TG14-AS
38	2E-Z2894	1	TERMINAL BLOCK (304)	
38	D9-GR0156	1	REAR PLATE ASSY.	
40	2C-Z2594	2	NUT 6-32 HEX W STL NP	
41	2C-Z3447	4	NUT 8-32 HEX W SS	
42	2C-1488	2	SCREW 6-32X3/8 RHP STL NP	
43	2I-Z3379	1	GROMMET-THERMOSTAT	
44	2I-Z3380	2	THERMOSTAT SEAL WASHER	
45	2M-Z19183	1	LABEL - CONTROL PANEL TSG	
46	2J-Y6689	1	PILOT LIGHT 120V	120V
	2J-Z2329		PILOT LIGHT	240V
47	D9-GR0709	1	KNOB ASSY PRO-MAX 2.0	
48	D9-GR0518	1	GREASE DRAWER ASSY	
49	2A-Z12946	4	2.5" FOOT BASE, 1/4-20	TG14-IS, TG14IG
50	2A-Z19356	4	BASE, FOOT, NON-SKID	TG14-IS, TG14IG
NI	2E-Z2905	1	CORD SJTO 12/3 NEMA 6-20P	240V
	2E-Z2935		CORD SJTO 14/3 NEMA 5-15P	120V
NI	2E-Z4119	1	POWER CORD, 12/3, 5-20P	120C