


**OPERATOR'S MANUAL  
HOLMAN CONVEYOR TOASTERS  
TURBOTOAST SERIES**

**PARTS LIST MODELS TT960, TT900H**



<u>PART #</u>	<u>QTY.</u>	<u>DESCRIPTION</u>	<u>PART #</u>	<u>QTY.</u>	<u>DESCRIPTION</u>
1). 100993	1	Top Cover	12). 150015	1	Drive Chain
2). 402407	1	Back Panel	13). 200700	2	Bushing, Idler Shaft
2a). 402408	1	Back Panel, (high)	14). 202902	1	Drive Shaft
2b). 401809	2	Side Panel	14a). 202905	1	Idler Shaft
2c). 401732	2	Side Panel (high)	15). 112261	2	Rear Bushing
3). 401726	1	Toast Chute Extension	16). 200561	1	Fan Motor
4). 101093	1	Crumb Tray	17). 200562	1	Fan Grill
5). 200762	1	Load Up tray	18). 200709	4	Leg, 1"
6). 197845	4	Heater Tubes, 208V	19). 200551	1	Power Saver Switch
6a). 197847	4	Heater Tubes, 240V	20a). 200538	2	Infinite Switch, 208/240V
6b). 197846	4	Heater Tubes, 220V	21). 115360	4	Knob
7). 4001917	1	Heater Tube Retainers	22). <a href="#">118042</a>	1	Speed control
8). 160024	1	Conveyor Belt	23). 140024	1	Cord/Plug set (not shown)
9). 200504	1	Drive Motor	24). 401698	1	Swinging Heat Shutter
10). 200645	1	Drive sprocket	25). 115146	1	High Limit Reset
11). 200645	1	Driven Sprocket	26). 200387	1	Fan Motor Cord Set (not shown)
			27). 200736	2	Spring, (not shown)

