

ARM-80

Parts List

Part#	Description
ARM-80-1	BOLT M6X10
ARM-80-2	NUT M32
ARM-80-3	BEARING CAP
ARM-80-4	BEARING #6307
ARM-80-5	PLASTIC PLUG
ARM-80-6	BOLT M8X30
ARM-80-7	NUT M32
ARM-80-8	SHAFT SUPPORT COVER
ARM-80-9	UPPER SPACER
ARM-80-10	SLOW SPEED GEAR COVER
ARM-80-11	SLOW SPEED GEAR SPRING
ARM-80-12	PIN M10X35
ARM-80-13	SLOW SPEED GEAR 12T
ARM-80-14	SLOW SPEED GEAR
ARM-80-15	ZERO BEVEL GEAR
ARM-80-16	UPPER CLUTCH GEAR
ARM-80-17	BUSHING
ARM-80-18	SLEEVE CLUTCH
ARM-80-19	SHAFT CENTER
ARM-80-20	KEY 10X10X60
ARM-80-21	KEY 10X10X40
ARM-80-22	KEY 10X10X90
ARM-80-23	BUSHING
ARM-80-24	LOWER CLUTCH GEAR
ARM-80-25	CENTER SHAFT BEARING
ARM-80-26	BEARING #5211
ARM-80-27	OIL SEAL 55X80X12
ARM-80-28	O RING
ARM-80-29	BEARING #6206
ARM-80-30	TRANSMISSION SHAFT
ARM-80-31	KEY 8X8X30
ARM-80-32	KEY 8X8X30
ARM-80-33	TRANSMISSION SHAFT GEAR
ARM-80-34	LOCK WASHER STW-40
ARM-80-35	GEAR
ARM-80-36	LOCK WASHER STW-35
ARM-80-37	BUSHING
ARM-80-38	SHIFT SHAFT
ARM-80-39	NUT M32
ARM-80-40	SPRING
ARM-80-41	SWITCH PIN

ARM-80-42	YOKE SHIFTER
ARM-80-43	BEARING #6205
ARM-80-44	BEARING #6205
ARM-80-45	KEY 8X8X30
ARM-80-46	WORM GEAR SHAFT
ARM-80-47	WORM WHEEL
ARM-80-48	LOCKWASHER STW-30
ARM-80-49	COVER
ARM-80-50	PLUG ATTACHMENT HUB
ARM-80-51	BOLT NM6X20
ARM-80-52	ATTACHMENT HUB
ARM-80-53	ATTACHMENT HUB SCREW
ARM-80-54	BUSHING
ARM-80-55	BEVEL DRIVE GEAR
ARM-80-56	SWITCH(ON)
ARM-80-56-1	SWITCH(OFF)
ARM-80-57	WARNING PLATE
ARM-80-58	MICRO SWITCH 3003
ARM-80-59	SWITCH BOARD 42X30X8
ARM-80-60	GEAR BOX
ARM-80-61	SPEED CHANGING MECH.
ARM-80-62	SPEED BALL M10
ARM-80-63	SPRING
ARM-80-64	OIL SEAL 20X30X6
ARM-80-65	SPEED CHANGING MECHANISM
ARM-80-66	LOCK WASHER STW-20
ARM-80-67	SWITCH PLATE
ARM-80-67	SWITCH PLATE
ARM-80-68	SELECTOR
ARM-80-69	TIMER
ARM-80-70	EMERGENCY BUTTON
ARM-80-71	SPEED CHANGING MECHANISM
ARM-80-72	SPEED CHANGING HANDLE
ARM-80-73	PLASTIC BALL M10X34
ARM-80-74	NUT 1/2X10MM
ARM-80-75	WASHER 23X39
ARM-80-76	WORM
ARM-80-77	OIL SEAL 30X47X7
ARM-80-78	O RING
ARM-80-79	GASKET
ARM-80-80	MOTOR
ARM-80-81	SPRING WASHER M10
ARM-80-82	BOLT M10X30
ARM-80-83	INTERNAL GEAR
ARM-80-84	BEARING
ARM-80-85	BOLT
ARM-80-86	BOLT

ARM-80-87	LOCKWASHER STW-30
ARM-80-88	BEATER SHAFT GEAR
ARM-80-89	BEARING #6207
ARM-80-90	KEY
ARM-80-91	BEATER SHAFT
ARM-80-92	BEATER PIN
ARM-80-93	BEARING #6208
ARM-80-94	OIL SEAL 40X80X12
ARM-80-95	WASHER
ARM-80-96	BOLT M12X25 S/S
ARM-80-97	SWITCH PUSHER
ARM-80-98	BOLT
ARM-80-99	SAFETY GUARD
ARM-80-100	SAFETY COVER
ARM-80-101	BOLT M8X20
ARM-80-102	BOWL
ARM-80-103	BEATER
ARM-80-104	HOOK
ARM-80-105	WHIP
ARM-80-106	MAIN SWITCH
ARM-80-107	DOOR LOCK
ARM-80-108	SWITCH BOX COVER
ARM-80-109	BOLT M4X40
ARM-80-110	MICRO SWITCH
ARM-80-111	SWITCH BOARD
ARM-80-112	APRON
ARM-80-113	BOLT
ARM-80-114	PEDESTAL
ARM-80-115	PEDESTAL COVER
ARM-80-116	BOLT
ARM-80-117	LOCKWASHER
ARM-80-118	GEAR
ARM-80-119	KEY
ARM-80-120	GEAR SHAFT
ARM-80-121	BEARING
ARM-80-122	BEARING HOUSING
ARM-80-123	BOLT
ARM-80-124	BEARING
ARM-80-125	LOCKWASHER
ARM-80-126	BOWL LIFT WHEEL
ARM-80-127	HANDLE
ARM-80-128	CHAIN GEAR (ELECTIC)
ARM-80-128	CHAIN GEAR (ELECTIC)
ARM-80-129	BOWL LIFT GEAR
ARM-80-130	BEARING
ARM-80-131	BUSHING
ARM-80-132	BEARING

ARM-80-133	KEY
ARM-80-134	SCREW (MANUAL)
ARM-80-135	WASHER
ARM-80-136	BOLT
ARM-80-137	BOLT
ARM-80-138	WASHER
ARM-80-139	BRASS NUT
ARM-80-140	BOLT
ARM-80-141	PIN
ARM-80-142	SLIDE WAY(L)
ARM-80-142-1	SLIDE WAY®
ARM-80-143	SLIDE WAY HOLDER(L)
ARM-80-143-1	SLIDE WAY HOLDER®
ARM-80-144	WASHER
ARM-80-145	BOLT
ARM-80-146	PLASTIC BALL
ARM-80-147	BOWL CLAMP(L)
ARM-80-148	BOWL CLAMP®
ARM-80-149	BOWL SUPPORT
ARM-80-150	CHAIN GEAR PIN
ARM-80-151	CHAIN GEAR
ARM-80-151-1	MOTOR PIN
ARM-80-152	CHAIN
ARM-80-153	SCREW
ARM-80-154	RING
ARM-80-155	WASHER
ARM-80-156	ELECTRICAL LIFT MOTOR
ARM-80-157	SCREW
ARM-80-158	MOUNTING BRACKET
ARM-80-159	BEARING
ARM-80-160	SPACER
ARM-80-161	BEARING
ARM-80-162	BOWL SUPPORT COVER
ARM-80-163	TRANSFORMER
ARM-80-164	RELAY
ARM-80-167	INGREDIENT CHUTE
ARM-80-169	NYLON CABLE GLAND
ARM-80-170	CABLE
ARM-80-171	BEARING
ARM-80-172	PLANETARY
ARM-80-173	BOLT
ARM-80-174	COVER BOLT
ARM-80-175	NUT
ARM-80-176	BOLT
ARM-80-177	KEY
ARM-80-178	WASHER
ARM-80-179	BOLT

ARM-80-180	BOLT
ARM-80-181	BOWL HOLDER STEEL
ARM-80-182	BEARING
ARM-80-183	SAFETY GUARD BEARING