

TDR-1380

Parts List

Divider

Part#	Description
TDR-1380D-2	SET SCREW
TDR-1380D-3	ARM, SELECTOR
TDR-1380D-4	LOCKING KNOB
TDR-1380D-5	SPRING
TDR-1380D-6	LOCK PIN
TDR-1380D-7	SCREW
TDR-1380D-8	TOP COVER, FRONT
TDR-1380D-9	EMERGENCY STOP SWITCH
TDR-1380D-10	HINGE
TDR-1380D-11	SCREW
TDR-1380D-12	FRONT SAFETY PANEL
TDR-1380D-13	BOLT
TDR-1380D-14	SAFETY MAGNET
TDR-1380D-15	NUT
TDR-1380D-16	HANDLE
TDR-1380D-17	SCREW
TDR-1380D-18	HOPPER EXTENSION
TDR-1380D-19	SCREW
TDR-1380D-20	MAGNET, SAFETY
TDR-1380D-21	SHAFT BUSHING
TDR-1380D-22	SHAFT BUSHING
TDR-1380D-23	GEAR
TDR-1380D-24	SCREW
TDR-1380D-25	MICRO SWITCH
TDR-1380D-26	HEX BOLT
TDR-1380D-27	NUT
TDR-1380D-28	MOUNTING BRACKET
TDR-1380D-29	PIN, LOCKING
TDR-1380D-30	PIVOT MOUNT
TDR-1380D-31	PADDLE, PUSH
TDR-1380D-32	BOLT
TDR-1380D-33	HOPPER CASE
TDR-1380D-34	SHAFT BUSHING
TDR-1380D-35	STRIP GEAR
TDR-1380D-36	SENSOR SWITCH
TDR-1380D-37	BOLT
TDR-1380D-38	HUB
TDR-1380D-39	KNOB
TDR-1380D-40	AUGER
TDR-1380D-41	KNOB

TDR-1380D-42	KNIFE
TDR-1380D-43	KNIFE HOLDING SET
TDR-1380D-44	BOLT
TDR-1380D-45	KEY
TDR-1380D-46	SHAFT
TDR-1380D-47	MOTOR, KNIFE
TDR-1380D-48	BOLT
TDR-1380D-49	BRACKET MOUNT
TDR-1380D-50	SCREW
TDR-1380D-51	MICRO SWITCH
TDR-1380D-52	COVER PLATE
TDR-1380D-53	SCREW
TDR-1380D-54	COLLAR BRACKET
TDR-1380D-55	WASHER
TDR-1380D-56	BOLT
TDR-1380D-57	BOLT
TDR-1380D-58	PANEL, RIGHT
TDR-1380D-59	CONTROL BOX
TDR-1380D-60	SCREW
TDR-1380D-61	BASE
TDR-1380D-62	BOLT
TDR-1380D-63	LOCK WASHER
TDR-1380D-64	WASHER
TDR-1380D-65	WASHER
TDR-1380D-66	LOCK WASHER
TDR-1380D-67	NUT
TDR-1380D-68	FOOT
TDR-1380D-69	FOOT PAD
TDR-1380D-70	BEARING
TDR-1380D-71	C CLAMP
TDR-1380D-72	BEARING
TDR-1380D-73	AUGER MOUNTING BRACE
TDR-1380D-74	MOTOR HOLDING BLOCK
TDR-1380D-75	BOLT
TDR-1380D-76	WASHER
TDR-1380D-77	BOLT
TDR-1380D-78	AUGER MOUNTING BRACE
TDR-1380D-79	AUGER DRIVE BLOCK
TDR-1380D-80	BOLT
TDR-1380D-81	BACK PANEL
TDR-1380D-82	KNOB
TDR-1380D-83	BOLT
TDR-1380D-84	CAP, SCREW HOLE
TDR-1380D-85	SCREW
TDR-1380D-86	CONTROL PANEL
TDR-1380D-87	TIMER UNIT
TDR-1380D-88	SCREW

TDR-1380D-89	MODE SELECTOR SWITCH
TDR-1380D-90	START SWITCH
TDR-1380D-91	STOP SWITCH
TDR-1380D-92	SCREW
TDR-1380D-93	CONTACTOR MOUNT PLATE
TDR-1380D-94	TRANSFORMER
TDR-1380D-95	CONTACTOR
TDR-1380D-96	COMPUTER CONTROL UNIT
TDR-1380D-97	TERMIAL BLOCK

Rounder

Part#	Description
TDR-1380R-1	DOUGH FUNNEL
TDR-1380R-2	AUGER RING
TDR-1380R-3	AUGER
TDR-1380R-4	SLEEVE CYLINDER
TDR-1380R-5	RUBBER BASE PAD
TDR-1380R-6	COLLAR PLATE
TDR-1380R-7	CLIP RING
TDR-1380R-8	ROLLER BEARING
TDR-1380R-9	BEARING, BALL
TDR-1380R-10	BOLT
TDR-1380R-11	DRUM TURN TABLE
TDR-1380R-12	BOLT
TDR-1380R-13	BOLT
TDR-1380R-14	DRUM TABLE MOUNT
TDR-1380R-15	NUT
TDR-1380R-16	BASE
TDR-1380R-17	CASTER
TDR-1380R-18	BOLT
TDR-1380R-19	TOP COVER, BACK
TDR-1380R-20	TOP COVER, FRONT
TDR-1380R-21	MOTOR
TDR-1380R-22	BOLT
TDR-1380R-23	NUT
TDR-1380R-24	MOTOR MOUNT
TDR-1380R-25	BOLT
TDR-1380R-26	BOLT
TDR-1380R-27	NUT
TDR-1380R-28	KEY
TDR-1380R-29	PULLEY
TDR-1380R-30	SET SCREW
TDR-1380R-31	DRIVE BELT
TDR-1380R-32	CONVEYOR GUARD LEFT
TDR-1380R-33	SCREW
TDR-1380R-34	CONVEYOR ROLLER, FRONY

TDR-1380R-35	CONVEYOR TENSION BAR
TDR-1380R-36	TENSIONING SCREW
TDR-1380R-37	NUT, TENSION
TDR-1380R-38	CONVEYOR TABLE
TDR-1380R-39	CONVEYOR GUARD, RIGHT
TDR-1380R-40	BOX MOUNTPLATE
TDR-1380R-41	SCREW
TDR-1380R-42	CONTACTOR BOX
TDR-1380R-43	CONTACTOR MOUNT PLATE
TDR-1380R-44	SCREW
TDR-1380R-45	EMERGENCY STOP SWITCH
TDR-1380R-46	START BUTTON
TDR-1380R-47	STOP BUTTON
TDR-1380R-48	SCREW
TDR-1380R-49	CONVEYOR SPEED CONTROLLER
TDR-1380R-50	ROUNDER CASE
TDR-1380R-51	BOLT
TDR-1380R-52	BOLT
TDR-1380R-53	SCREW
TDR-1380R-54	CONVEYOR MOUNT, LEFT
TDR-1380R-55	CONVEYOR BELT
TDR-1380R-56	BOLT
TDR-1380R-57	SCREW
TDR-1380R-58	CONVEYOR MOUNT, RIGHT
TDR-1380R-59	SCREW
TDR-1380R-60	CONVEYOR DRIVE MOTOR
TDR-1380R-61	ROLLER/ MOTOR MOUNT
TDR-1380R-62	KEY
TDR-1380R-63	CONVEYOR DRIVE ROLLER
TDR-1380R-64	BUSHING, DRIVE ROLLER
TDR-1380R-65	ROLLER MOUNT, RIGHT
TDR-1380R-66	ANGLE BRACKET
TDR-1380R-67	SCREW
TDR-1380R-68	BRACKER, SWITCH MOUNT
TDR-1380R-69	MAGNETIC SWITCH, SAFETY
TDR-1380R-70	CONTACTOR