

# TMS-3600

## Parts List

Part#	Description
TMS-3600-1	UPPER DOOR
TMS-3600-2	KNOB M8X27
TMS-3600-3	SCREW BAR
TMS-3600-4	LOCK SCREW M6
TMS-3600-5	HEXSCREW M6X12
TMS-3600-6	HINGE
TMS-3600-7	BOLT M5-10
TMS-3600-8	MOTOR COVER
TMS-3600-9	BOLT M3-6
TMS-3600-10	EMERGENCY STOP BUTTOM
TMS-3600-11	START BUTTON R2PNF-22
TMS-3600-12	STOP BUTTON R2PNF-22
TMS-3600-13	ON/ OFF SWITCH BOX
TMS-3600-14	SCREW
TMS-3600-15	PULLEY ADJUSTER CAP
TMS-3600-16	NUT M10
TMS-3600-17	WASHER
TMS-3600-18	SPRING
TMS-3600-19	PIPE
TMS-3600-20	SCREW BAR
TMS-3600-21	PULLEY ADJUSTER
TMS-3600-22	ADJUST WASHER (UPPER)
TMS-3600-23	ADJUST WASHER (LOWER)
TMS-3600-24	ADJUST SCREW 12X19
TMS-3600-25	KEY 4X4X6
TMS-3600-26	BUSHING
TMS-3600-27	SQUARE BLOCK #304 19X19X61
TMS-3600-28	ADJUSTABLE BLOCK
TMS-3600-29	PIN
TMS-3600-30	BOLT M5-10
TMS-3600-31	FRONT PANEL
TMS-3600-32	FIXED SCREW
TMS-3600-33	HEXSCREW M6-12
TMS-3600-34	BRASS BLOCK 30X60X19
TMS-3600-35	MOTOR
TMS-3600-36	HEXSCREW M8X25
TMS-3600-37	HEXSCREW M6X12
TMS-3600-38	HINGE BR-70-1
TMS-3600-39	KEY 7X7X30
TMS-3600-40	SHAFT BUSHING
TMS-3600-41	FRAME

TMS-3600-42	BLADE SHAFT
TMS-3600-43	SCREW M6-40
TMS-3600-44	LOCK KNOB
TMS-3600-45	RUBBER PUSHING
TMS-3600-46	BEARING
TMS-3600-47	UPPER PULLEY
TMS-3600-48	PUSHING
TMS-3600-49	BEARING #6203
TMS-3600-50	C CLAMP STW-16
TMS-3600-51	PULLEY CAP
TMS-3600-52	HEXSCREW
TMS-3600-53	ADJUST BAR
TMS-3600-54	FIXED BLOCK 54X54X50
TMS-3600-55	BLADE SAFTY COVER
TMS-3600-56	HEXSCREW M5-10
TMS-3600-57	ALUMINUM ADJUST PIECE 25.4X50.
TMS-3600-58	BLADE PROTECTECTION BOLT#304 1
TMS-3600-59	ADJUST SCREW 12X19
TMS-3600-60	PE PLATE
TMS-3600-61	WASHER M8
TMS-3600-62	BLADE HOLDER
TMS-3600-63	HEXSCREW M8X20
TMS-3600-64	BLADE
TMS-3600-65	WASHER M8
TMS-3600-66	HEXSCREW M8X10
TMS-3600-67	HEXSCREW M10-35
TMS-3600-68	WASHER M10
TMS-3600-69	CAP NUT M8
TMS-3600-70	NUT M10
TMS-3600-71	SHAFT
TMS-3600-72	BEARING LM12UU
TMS-3600-73	MEAT PUSHER
TMS-3600-74	SCREW M4X6
TMS-3600-75	PLASTIC NUT
TMS-3600-76	BUSHING
TMS-3600-77	SLIDE RAIL
TMS-3600-78	PLASTIC HANDLE (HY-353 P120)
TMS-3600-79	SCREW M8X20
TMS-3600-80	WORKING TABLE
TMS-3600-81	BLADE CLEANER
TMS-3600-82	PLASTIC BLADE CLEANER
TMS-3600-83	ADJUST ALUMINUM BLOCK
TMS-3600-84	HEXSCREW M10X35
TMS-3600-85	WASHER
TMS-3600-86	LOWER PULLEY
TMS-3600-87	OIL SEAL 25X40X9
TMS-3600-88	HEXSCREW M5X8

TMS-3600-89	PLASTIC NUT
TMS-3600-90	O RING
TMS-3600-91	NUT M8
TMS-3600-92	PIN
TMS-3600-93	SPRING
TMS-3600-94	LARGE FIBER PIECE 65X37X16
TMS-3600-95	WASHER
TMS-3600-96	NUT M8
TMS-3600-97	HEXSCREW M6X15
TMS-3600-98	WASHER M6
TMS-3600-99	SMALL FIBER PIECE 38X12X5
TMS-3600-100	BLADE CLEANER
TMS-3600-101	SHAFT
TMS-3600-102	STEEL SCRAPER
TMS-3600-103	CONTROL BOX (DS-AG-1725-1)
TMS-3600-104	CONTROL BOX (DS-AG-1725-1)
TMS-3600-105	CAPACITOR
TMS-3600-106	SCREW 3/16X1/4
TMS-3600-107	SCREW M8X35
TMS-3600-108	HEXSCREW M6X15
TMS-3600-109	BOTTOM PLATE
TMS-3600-110	BASE
TMS-3600-111	NUT M5
TMS-3600-112	NUT
TMS-3600-113	SCREW BAR
TMS-3600-114	CUTTING PLATE
TMS-3600-115	DRAWER
TMS-3600-116	PLASTIC HANDLE
TMS-3600-117	HEXSCREW
TMS-3600-118	PAD