


# USER GUIDE

## Parts



<b>UHBV518-SG41A</b>		
1	ANTI-TIP BRACKET	80-55449-00
2	BACK PANEL	80-55474-00
3	BIN, STORAGE	<a href="#">80-54050-00</a>
4	BIN FRONT	80-55475-00
5	COMPRESSOR	80-55452-00
6	CONDENSER ASSEMBLY	80-55453-00
7	CONDENSER FAN	<a href="#">80-54014-00</a>
8	DISPLAY MODULE	80-55429-00
9	DOOR ASSEMBLY	80-55496-00
10	DRAIN PAN	<a href="#">80-54217-00</a>
11	DRIER	<a href="#">80-54055-00</a>
12	EVAPORATOR ASSEMBLY	80-55478-00
13	EVAPORATOR COVER	80-55477-00
14	EVAPORATOR FAN W/COVER	80-55457-00
15	GASKET, DOOR	80-55517-00
16	GLASS SHELF	<a href="#">80-54049-00</a>
17	GRILLE	80-55479-00
18	HINGE ASSEMBLY	80-55374-00
19	HINGE COVER (2)	<a href="#">80-54001-00</a>
20	LEG LEVELERS (4)	<a href="#">80-54019-00</a>
21	LED LIGHT, 2 COLOR	80-55272-00
22	MAIN BOARD	<a href="#">80-55398-00</a>
23	PLUNGER SWITCH	80-55375-00
24	POWER CORD*	80-55462-00
25	SERIAL INVERTER, 115V	80-55570-00
26	SLIDE ASSEMBLY	80-55509-00
27	THERMISTOR	<a href="#">80-54006-00</a>
28	THERMISTOR COVER	80-55464-00
29	WINE RACK	80-55480-00
30	WINE RACK FRONT	80-55501-00
31	WIRE HARNESS, BOARD*	80-55466-00

\*Not Shown