


# USER GUIDE

## Parts



UHBV524-SG41A		
1	ANTI-TIP BRACKET	80-55449-00
2	BACK PANEL	80-55481-00
3	STORAGE BIN	<a href="#">80-54059-00</a>
4	BIN FRONT	80-55482-00
5	COMPRESSOR W/ELECTRICALS	80-55452-00
6	CONDENSER ASSEMBLY	80-55453-00
7	CONDENSER FAN MOTOR	<a href="#">80-54014-00</a>
8	DISPLAY MODULE	80-55429-00
9	DOOR ASSEMBLY	80-55492-00
10	DRAIN PAN	<a href="#">80-54217-00</a>
11	DRIER	<a href="#">80-54055-00</a>
12	EVAPORATOR ASSEMBLY	80-55486-00
13	EVAPORATOR COVER	80-55485-00
14	EVAPORATOR FAN W/COVER	80-55457-00
15	GASKET, DOOR	<a href="#">80-54039-00</a>
16	GLASS SHELF	80-55460-00
17	GRILLE	80-55487-00
18	HINGE ASSEMBLY	80-55374-00
19	HINGE COVER (2)	<a href="#">80-54001-00</a>
20	LEG LEVELERS (4)	<a href="#">80-54019-00</a>
21	LED LIGHT, 2 COLOR	80-55272-00
22	MAIN BOARD	<a href="#">80-55398-00</a>
23	PLUNGER SWITCH	80-55375-00
24	POWER CORD	80-55462-00
25	SLIDE ASSEMBLY	80-55509-00
26	THERMISTOR	<a href="#">80-54006-00</a>
27	THERMISTOR COVER	80-55464-00
28	WINE RACK	80-55488-00
29	WINE RACK FRONT	80-55502-00
30	WIRE HARNESS, BOARD	80-55466-00