


# USER GUIDE

## Parts



<b>UHWC524-SG41A</b>		
1	ANTI-TIP BRACKET	80-55449-00
2	BACK PANEL	80-55481-00
3	COMPRESSOR W/ELECTRICALS	80-55452-00
4	CONDENSER ASSEMBLY	80-55453-00
5	CONDENSER FAN MOTOR	<a href="#">80-54014-00</a>
6	DISPLAY MODULE	80-55429-00
7	DOOR ASSEMBLY	80-55492-00
8	DRAIN PAN	<a href="#">80-54217-00</a>
9	DRIER	<a href="#">80-54055-00</a>
10	EVAPORATOR ASSEMBLY	80-55486-00
11	EVAPORATOR COVER	80-55485-00
12	EVAPORATOR FAN W/COVER	80-55457-00
13	GASKET, DOOR	<a href="#">80-54039-00</a>
14	GRILLE	80-55487-00
15	HINGE ASSEMBLY	80-55374-00
16	HINGE COVER (2)	<a href="#">80-54001-00</a>
17	LEG LEVELERS (4)	<a href="#">80-54019-00</a>
18	LED LIGHT, 2 COLOR	80-55272-00
19	MAIN BOARD	<a href="#">80-55398-00</a>
20	PLUNGER SWITCH	80-55375-00
21	POWER CORD*	80-55462-00
22	SLIDE ASSEMBLY	80-55509-00
23	THERMISTOR	<a href="#">80-54006-00</a>
24	THERMISTOR COVER	80-55464-00
25	WINE RACK	80-55488-00
26	WINE RACK FRONT	80-55502-00
27	WIRE HARNESS, BOARD*	80-55466-00

\*Not Shown