










500664
2 Piece Lid (center lid 011700)







501114
Container with
Blending Assy.



WARING
COMMERCIAL

BB1000 /plastic container
BC1000 /CSA w/ plastic container
These Units Are No Longer In Production



Catalog	Model
BB1000	35BL37
BC1000	34BL59



Illustration#	Part#	Description
1	003146	Center Lid /BB1000
2	011700	Center Lid /BC1000
3	013442	Outer Lid
4	003504	Cap Nut
5	003302	Blade
6	003609	Washer /stainless steel
7	002903	Washer
8	003601	Shaft
9	009778	Bearing Holder
10	009724	Washer /nylon
11	003537	Washer /stainless steel
12	003509	Washer /neoprene
13	014549	Plastic Container /48 oz
14	013304	NSF Seal
15	015055	Container Adapter
16	009780	Hex Nut /left hand thread
17	003526	Washer /phenolic
18	006937	Washer /stainless steel
19	003138	Coupling
20	003137	Jar Pad 4 Req.'d
21	007967	Jar Pad Stud 4 Req.'d
22	014009	Coupling (003609 washer if req.'d for gap)
23	017289	Plated Top Cover
24	012752	Seal 4 Req.'d
25	012751	Spacer 4 Req.'d
26	003563	Baffle
27	015165	Nut 4 Req.'d
28	018594	Housing Seal
29	016111	Base (top housing)
30	014899	Name Plate

Catalog
BB1000
BC1000

Model
35BL37
34BL59

Waring Factory Service Center
314 Ella T. Grasso Ave.
Torrington, CT 06790
Tele. 1-800-269-6640
Fax 860-496-9017
www.waringproducts.com

Illustration#	Part#	Description
31	003532	Rivet /name plate 2 Req.'d
32	012698	Switch
33	012703	Switch Seal (boot)
34	024030	Motor
35	009051	Wire Nut 2 Req.'d /BB1000
	012409	Crimp Connector 2 Req.'d /BC1000
36	500916	Lead & Diode (003262)
37	013731	Cable Tie /BC1000
38	013270	Screw /ground
39	002881	Nut /ground
40	501039	Bottom Plate with Screen ONLY
	501206	Bottom Plate Assy. with Cord Set
41	014553	Cord Clamp
42	007558	Screw
43	002957	Nut
44	501205	Cord Set
45	002891	Foot 3 Req.'d
46	003569	Screw 3 Req.'d
47	016211	Foot Plug 3 Req.'d

