


Unit Information


800 Watts – 1+ HP
2 Yr. Unit Warranty
3 Yr. Motor Warranty
12 mixing speeds with
soft start

WARING
COMMERCIAL
7-Quart Stand Mixer
WSM7Q




WARING COMMERCIAL

503190 Unit Assembly





| Illustration # | Part # | Description |
|----------------|------------------|--|
| 1 | 029128 | Top Cover |
| 2 | 029906 | Screw (3 required) |
| 3 | 029907 | Spigot |
| 4 | 029908 | Spigot Seat Plate |
| 5 | 503294 | Front Cover Assembly |
| 6 | 035166 503295 | Middle Cover Assembly <i>(on units after 8/2012)</i> Middle Cover Assembly <i>(unit has bracket no longer used)</i> |
| 7 | 029909 | Screw (2 required) |
| 8 | 029910 | Knob |
| 9 | 503296 | Lower Cover Assembly |
| 10 | 029911 | Body |
| 11 | 029912 | Control |
| 12 | 503297 | Gear Box Assembly |
| 13 | 029913 | Pedestal |
| 14 | 029914 | Cord |
| 15 | 029915 | Feet (4 required) |
| 16 | 029131 | Splash Guard |
| 17 | 029130 | Bowl |
| 18 | 029132 | Whisk |
| 19 | 029134 | Paddle |
| 20 | 029133 | Dough Hook |
| 21 | 029129 | Bowl Pad |
| 22 | 029916 | Quadrant |
| 23 | 503298 | Quadrant Spindle Assembly |
| 24 | 029917 | Ground Washer |
| 25 | 029918 | Ground Screw |
| 26 | 029919 | Control Bracket |
| 27 | 029920 | Screw (3 required) |
| 28 | 029921 | Hex Head Bolt (2 required) |
| 29 | 029923 | Timing Belt |
| 30 | 029924 | Spacer (2 required) |
| 31 | 029925 | Felt Pad |
| 32 | 029918 | Screw (4 required) |
| 33 | 029926 | Screw (3 required) |

| Illustration # | Part # | Description |
|----------------|--------|----------------------------|
| 34 | 029927 | Motor Bushing (3 required) |
| 35 | 029928 | Washer |
| 36 | 029929 | Motor |
| 37 | 029930 | Hinge Retainer |
| 38 | 029918 | Screw (2 required) |
| 39 | 503299 | PC Board Assembly |
| 40 | 503300 | PC Board Assembly Cover |
| 41 | 029931 | Screw (2 required) |
| 42 | 029932 | Quadrant Bracket |
| 43 | 029918 | Screw (2 required) |
| 44 | 029933 | Strain Relief |
| 45 | 029934 | Lower Cord Clamp |
| 46 | 029918 | Screw (4 required) |
| 47 | 029935 | Balance Spring |
| 48 | 029936 | Hinge Pin |
| 49 | 029937 | E Ring |
| 50 | 029938 | Quadrant Spindle Support |
| 51 | 029939 | Head Release Spring |



Part No Longer Used

029922 - Bracket
(no longer available)



Wiring Diagram