




SIDE BY SIDE REFRIGERATOR

MODELS:

KRSC500ESS01 (Stainless)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	15		Hinge, Bottom (Freezer)	25	W10001250	Screw
	W10768946	Use & Care Guide				26	W10279882	Tube, Filter Inlet
	W10751694	Service & Wiring Sheet		W11126848	Grey	27	W10279885	Tube, Filter Outlet
	W11098958	Energy Guide	16		Hinge, Bottom (Refrigerator)	28	W10370680	Fitting, Drain
2	2150304	Roller		W11084346	Grey	29	12957702	Lid, HV Box
3	W10297485	Screw	17		Closer, Door (Refrigerator)	30	W10797301	Electronic Control
4	12477102	Roller				31		Cabinet (Not A Serviceable Part)
5	12477202	Axle, Roller		W10877804	Grey	32	W10247993	Box, Control
6	981125	Rivet, Roller	18	W10141645	Screw	33	W10257238	Cover, Unit
7	W10369091	Tube, Drain	19	549193	Clamp, Power Cord	34	2223388	Clip, Axle Retainer
8	W10900758	Bracket, Foot	20	W10226427	Control, Electronic (Power Supply)	35	W11175631	Locking Ring (5/16)
9	W10141622	Brake, Roller					W11175632	Locking Ring (1/4)
10	W10308751	Screw (Black)	21		Filler, Wrapper	36	W10341320	Assembly, Dual Water Valve
11	W10498992	Valve, Inlet		12587703AP	Grey	37	W10691732	Tube, Water
12		Hinge, Top (Freezer)	22		Grille	38	W10141625	Screw
	W10901054	Grey		W10713153	Grey	39	W10237915	Bracket, Water Valve
13		Hinge, Top (Refrigerator)	23	W10142234	Screw	40	W10336736	Cover, Roller
	W10901049	Grey	24		Closer, Door (Freezer)			
14	W10308489	Screw (Grey)		W10770893	Grey			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	11	W10315189	Filter, Air	19	W10862282	Support, Evaporator (Left Hand)
2	W10387382	Cover, Evaporator	12	W10341548	Cover, Air Filter	20	W10826780	Lighting, LED-Strip
3	W10735398	Filter, Water	13	W10394053	Housing, Water Filter	21	W10394945	Gasket, Rear
4	W10323459	Thermistor, Evaporator Fan	14	W10425252	Cover, Thermistor	22	W10724473	Assembly, LED
5	W10903407	Tower, Air	15	W10876279	Assembly, LED Light Module	23	W10260462	Gasket, Rear
6	W10847853	Switch, Light	16	W10300482	Cover, Water Filter	24	W10387387	Gasket, Upper
7	W10538994	Reservoir	17	W10862076	Fan Assembly, Evaporator			
8	W10271541	Connector, Union	18	W10862067	Evaporator Insulation, With Fan Assembly			
9	W10280385	Thermistor						
10	W10223364	Support, Evaporator (Right Hand)						


REFRIGERATOR SHELF PARTS



REFRIGERATOR SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10440265	Cover, Assembly	10	W10395554	Wine Rack	17		Rail, Track
2	W10440266	Cover, Assembly	11	W11180785	Assembly, Shelf		W10247942	Left Side
3	W10542037	Pan, Snack	12	W10542020	Trim, Handle		W10247940	Right Side
4	W10628713	Roller, Pan	13	W10531022	Trim, Handle	18		Rail, Track
5	W10628712	Axle, Roller	14	W10531023	Trim, Handle		W10805083	Left Side
6	W10531081	Pan, Crisper	15	W10408747	Holder, Filter		W10805082	Right Side
7	W10531082	Pan, Meat	16	W10346771	Filter, Produce Preserver			
8	W10316452	Housing, Humidity						
9	W10257334	Slide, Humidity						



FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	5	W11180790	Shelf Assembly, Lower	10	W10847849	Switch, Light
2	W10644644	Cover Assembly	6	W10725170	Freezer Pan, Middle	11	W10425252	Cover, Thermistor
3	W11180789	Shelf Assembly, Upper	7	W10628713	Roller, Pan	12	W10724473	Assembly, LED
4	W10280386	Thermistor	8	W10628712	Axle, Roller	13	W10542017	Trim, Handle
			9	W10726001	Freezer Pan, Lower	14	W10826780	Lighting, LED-Strip


ICEMAKER AND ICE CONTAINER PARTS



ICEMAKER AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10781441	Assembly, Ice Bin	9	W10781442	Bin, Ice	16	W10646076	Assembly, Wire Jumper Switch
2	W10693542	Assembly, Latch	10	W11117906	Motor, Dispenser	17	W10765378	Assembly, Motor Box
3	2220458	Coupling, Bottom	11	W10669473	Cover, Container	18	W10166854	Gasket
4	W10258544	Shaft, Drive	12	W10691248	Plate, Switch	19	W11130444	Assembly, Ice Maker
5	W10754509	Spring, Coupling	13	W10666871	Rocker, Switch			
6	W11240062	Assembly, Mounting Plate	14	W10656772	Switch, Rocker Arm			
7	W10400435	Gasket, Foam	15	W10749467	Filler, EPS Icemaker Cover			
8	W10291905	Gasket						


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator (Includes Item 5)	7	2200086	Thimble, Top	14		Cover, Door Stop
	W10757191	Stainless	8	W10460893	Screw		W10789147	Grey
2	W10316457	Bin, Gallon Door	9		Closer, Upper Cam Door	15	W10324760	Assembly, Utility Compartment
3	W10296816	Screw		W10257203	Grey	16	W10494334	Frame, Gallon Door Bin
4	W10316461	Bin, Shallow Door	10	W11204458	Screw	17	W10494333	Frame, Shallow Door Bin
5		Gasket, Door	11	W10888898	Bracket, Door Stop			
	W10249916	Grey	12	W10518672	Badge			
6		Handle	13	W10010140	Set Screw (Silver)			
	W11252159	Stainless						


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Item 6 And Dispenser Front Parts)	3	2200086	Thimble, Top	8	W10494336	Frame, Door Bin
	W10726007	Stainless	4	W10460893	Screw	9	W10323148	Cover, Wire
2		Handle	5	W10434529	Bin, Door			
	W11252159	Stainless	6		Gasket, Door			
				W10249917	Grey			
			7	W10010140	Set Screw (Silver)			


DISPENSER PARTS



DISPENSER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Wall, Dispenser False	8	4449745	Screw	13		Tray, Housing
	W10317255	Stainless	9	W10781990	Assembly, Ice Door		W10317261	Stainless
2	W10317270	Grate, Drip Tray	10	W10238083	Assembly, LED	14		Drip Tray, Insert
3	W10691730	Tube, Water	11	W10798790	User Interface Assembly		W10317276	Grey
4	W10435760	Guide, Ice			Pad, Ice and Water	15	W10386778	Assembly, Water Fitting
5	W10205978	Motor, Dispenser	12			16	W10605336	Harness, Wire
6	W10353593	Assembly, Seperator		W10346924	Grey			
7	W10346124	Support, Ice Door						


AIR FLOW PARTS



AIR FLOW PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10251462	Scroll, Fan	8	2169142	Blade, Fan	14	W10388268	Cover, Evaporator
2	2223733	Retainer, Fan Motor	9	W10240370	Gasket, Evaporator Cover	15	W10260382	Cover, Light
3	W10260380	Duct, Upper Air	10	W10449920	Grommet, Motor	16	W10331728	Clip, Air Duct
4		Bi-Metal Defrost (Not Serviced)	11	W10369602	Clip, Evaporator Cover	17	W11205489	Foam
5	W10382898	Duct, Freezer Air	12	W10679946	Assembly, Evaporator Fan Wire (Includes Bi-Metal Defrost)			
6	W10001260	Screw						
7	W10556724	Motor, Fan	13	W10142292	Screw			

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10271543	Connector, Water Tube	16	2188822	Evaporator	31	W10643261	Evaporator, Dual-RC
2	2225834	Blade, Fan	17	2161324	Clip, Defrost Heater	32	W10317862	Pan, Drip
3	W10240365	Assembly, Condenser	18	W10909387	Motor, Condenser Fan	33	W10868747	Coil, 3 Way Valve
4	W10142255	Screw	19	W10714793	Tray, Evaporator (Includes Gasket)	34	2169104	Insulation, Sound Deadening
5	W10862105	Tube, Drain	20	W10348669	Heat Shield			REFRIGERANT CHARGE
6	W10171469	Screw	21	W10286069	Drier			5.75 oz. (R-134A)
7	W10277958	Connector, Water	22	W10679948	Assembly, Unit Wire			
8	W10303521	Sleeve	23	W10680691	Baseplate			
9	W10142287	Screw	24	W10242407	Cord, Power			
10	W10815861	Clip, Bottom Cover	25	W10251467	Baffle, Air			
11	W10223328	Tube, Suction	26	W10495967	Heater, Defrost			
12	W10248621	Clip, Condenser	27	W10284726	Cover, Unit Bottom			
13	W10710090	Assembly, Inverter Box	28	W10695094	Compressor			
14	2325479	Tube, Process	29	2183042	Grommet			
15	2205813	Tie, Wire	30	W11034126	Assembly, 3 Way Valve			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350942	White Primer
	350939	Enamel, Black
	350930	White
	4392901	Biscuit/Bisque
	8171357	Graphite

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	80051	Graphite

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque
	8171358	Graphite

MISCELLANEOUS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	W10300794	Kit, Handle Installation
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	4318168	Sealer
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key