HOBART


CATALOG OF REPLACEMENT PARTS

HRO101 SERIES
Rotary Ovens & Warmer


HRO101	ML-43775
HRW101	ML-43777

A product of HOBART CORPORATION 701 RIDGE AVENUE TROY, OHIO 45374-0001

FORM 18525 (11-92)




HRO101



HRO101
WARMER = HRW101

PL-50947


©HOBART CORPORATION, 1992



DOOR

ILLUS. PL-50914	PART NO.	NAME OF PART	AMT.
1	356848	Cover - Door Glass Profile (Oven)	1
2	356855	Cover - Door Glass Profile (Warmer)	1
3	356940	Bracket - Hinge Door	1
4	360142	Glass - Door (17 x 23) (Oven)	1
5	360447	Glass - Door (23 x 26) (Warmer)	1
6	356849	Holder - Magnet (Oven)	1
7	356856	Holder - Magnet (Warmer)	1
8	356850	Magnet - Door	11
9	356851	Cap - Handle End	2
10	356852	Handle - Door (Operator's Side Only) (Oven)	1
11	356913	Handle - Door (Warmer)	1
12	356853	Holder - Glass (Customer's Side)(Oven)	1
13	356846	Holder - Glass (Operator's Side)(Oven)	1
14	356882	Holder - Glass (Customer's Side)(Warmer)	1
15	356881	Holder - Glass (Operator's Side)(Warmer)	1
16	357114	Bushing - Door	1


* Note: Quantities Listed Are For One (1) Door Only.



CONTROL PANEL

CONTROL PANEL


ILLUS. PL-50915	PART NO.	NAME OF PART	AMT.
1	360145	Thermostat (Oven)	1
2	360281	Clip - Thermostat	2
3	360036	Thermometer (Warmer)	1
4	356939	Control - Clock	1
5	360145	Thermostat High-Limit (Oven)	1
6	356830	Switch - Rotary (Oven)	1
7	356878	Switch - Main (On/Off) (Warmer)	1
8	356839	Switch - Main (On/Off) (Oven)	1
9	360034	Thermostat (Warmer)	1
10	356941	Switch - Magnet	1
11	356938	RC Unit	1
12	356842	Bracket - Terminal Black Mounting	1
13	360201	Capacitor	1
14	356841	Block - Terminal	1
15	360280	Plate - Ground	1
16	356857	Block - Terminal	1
17	356829	Panel - Electrical Component	1
18	356867	Control Panel Assy. (Operator's Side) (Warmer)	1
19	356833	Knob - Switch (Warmer)	1
20	356823	Control Panel Assy. (Operator's Side) (Oven)	1
21	356840	Holder - Fuse	2
22	356845	Fuse	2
23	356833	Knob - Switch (Warmer)	3
24	356843	Clock - Digital (Display)	1
25	356947	Bracket - Thermostat & Switch	1
26	356946	Sensor - Temperature (Oven)	1
	356835	Cord & Plug (Not Shown)	1



ROTISSERIE

ROTISSERIE


ILLUS. PL-50916	PART NO.	NAME OF PART	AMT.
1	356813	Element - Heating (1250 Watts Each Unit)	2
2	356832	Plate - Lamp Holder W/Air Slots	1
3	360152	Fork - Meat	4
4	356858	Motor	1
5	360131	Bearing - Drive	1
6	360137	Seal - Ring	1
7	360134	Shaft - Rotor	1
8	360132	Disc - Stud	1
9	360133	Disc - Rotor	2
10	360130	Bearing - Rotor Disc	1
11	360156	Holder - Quartz Lamp Cap	4
12	360155	Lamp - Quartz	2
13	360129	Holder - Quartz Lamp Base	4



BLOWER

BLOWER


ILLUS. PL-50917	PART NO.	NAME OF PART	AMT.
1	356812	Deflector - Air	1
2	356811	Blower	1
3	356814	Plate - Blower Mounting	1
4	356810	Plate - Ceiling	1


1 - 2
3
4
5
6
7
8
9 - 10
11
12 - 13
14 - 15
16
17
18
19 - 20
21
22
23- 24 - 25
26
27
28
PL-50918

OVEN

OVEN


ILLUS. PL-50918	PART NO.	NAME OF PART	AMT.
1	356865	Panel - Outer (L.H.) (HRW 101)	1
2	356821	Panel - Outer (R.H.) (HRO 101)	1
3	356820	Bearing Plate - Open Reinforcement	1
4	356809	Top Assy.	1
5	356815	Panel - Inner Oven Side (L.H.)	1
6	356816	Panel - Inner Oven Side (R.H.)	1
7	356828	Plate - Bottom	2
8	356937	Block - Connection	1
9	356826	Panel - Lower Front (Customer Side) (HRO 101)	1
10	356868	Panel - Lower Front (Customer Side) (HRW 101)	1
11	356818	Reinforcement - Profile (Customer's Side)	1
12	356822	Panel - Outer (R.H.) (HRO 101)	1
13	356866	Panel - Outer (R.H.) (HRW 101)	1
14	356824	Panel - Customer Side (Oven)	1
15	356869	Panel - Customer Side (Warmer)	1
16	356880	Tray - Spark (Thermostat) (Warmer)	2
17	356819	Plate - Main Mounting	1
18	356859	Foot (HRO 101)	4
19	356844	Box - Sparking (Motor)	1
20	356831	Plate - Motor Mounting	1
21	360143	Bushing	1
22	356817	Reinforcement - Profile (Operator's Side)	1
23	356871	Water Drawer Assy. (HRW 101) (Lower Drawer)	1
24	356870	Grease Drawer Assy. (HRW 101) (Upper Drawer)	1
25	356827	Grease Drawer Assy. (HRO 101)	1
26	360206	Gasket - Drain	1
27	360205	Gasket - Seat	1
28	356825	Panel - Lower Front (Operator's Side)	1



WARMER

WARMER

ILLUS. PL-50919	PART NO.	NAME OF PART	AMT.
1	356943	Duct - Air	1
2	356877	Plate - Fan Mounting	1
3	356811	Blower	1
4	356862	Panel - Inner Oven Side (R.H.) (Warmer)	1
5	356814	Plate - Blower Mounting	1
6	356819	Plate - Main Mounting	1
7	360443	Caster W/Lock	2
8	360444	Caster W/O Lock	2
9	356876	Spacer	4
10	356942	Support - Lower	2
11	356834	Plate - Reinforcement	4
12	360047	Element - Heating	1
13	356949	Plate - Cover	1
14	356825	Panel - Lower Front (Operator's Side)	1
15	360446	Lamp - Halotherm 200W	1
16	360240	Holder - Lamp	2
17	356861	Lamp - Reflector (Halogen)	1
18	356863	Panel - Inside (L.H.)	1
19	356860	Plate - Ceiling	1




PL-50920

RACKS AND TRAYS

RACKS AND TRAYS

ILLUS. PL-50920	PART NO.	NAME OF PART	AMT.
1	360136	Spacer - Fan Guard	4
2	356874	Fan Cover Warmer Assy.	1
3	356875	Plate - Bottom	1
4	356879	Rack - Stainless Steel Wire	3
5	356872	Rack Slide Assy.	1



PL-21085-1

ACCESSORIES

ILLUS. PL-21085-1	PART NO.	NAME OF PART	AMT.
1	360298	Sleeve - Spit	1
2	360299	Fork - Spit	AR
3	360300	Shaft - Spit	1
4	360279	Spit - Turkey Assy. (Incls.items 1,2,3 & 5)	1
5	360297	Screw - Wing M5	AR
6	360385	Glide Pin	1
7	SL-5-8	Spring - Loading	2
8	NS-47-13	Nut - Hex M6 x 1.0	2
9	360383	Plate - Baking	1
10	360278	Plate - Baking Assy. (Incls.items 6 thru 9 & 11 thru 13)	1
11	360384	Drag Pin	1
12	SL-5-8	Spring - Loading	2
13	NS-47-13	Nut - Hex M6 x 1.0	2
	360277	Basket	1
	360284	Key - Spit	1