


**Unit Information**

	1 HP – 1.1 Amps.		
	3 Speeds with Pulse Operation		
RPM's	15000	18000	21000
	Low	Med	High



Single Head Electronic Drink Mixer  
**WDM120TX**




Illustration#	Part#	Description
1	037532	Hole Plugs (4 required)
2	033901	Screw (4 required)
3	037533 037534	Top Cover Top Cover with Air Guards
4	037126	Top Cover Air Guards
5	033886	Screw (2 required)
6	030689	Name Plate
7	030690	Washer (2 required)
8	030691	Screw (2 required)
9	037535	Control Panel
10	037536	Fiber Washer (2 required)
11	030706	Screw (2 required)
12	037537	Housing
13	013791	Wire Tie (4 required)
14	037538	Actuator Switch
15	033901	Screw (2 required)
16	030696	Washer (2 required)
17	030703	Sleeve (2 required)
18	037539	Spring
19	037540	Lead Tape
20	037541	Lead Harness
21	037542	Power Board Holder
22	037543	Screw (6 required)
23	037544	Power Board
24	033881	Press Lock Stand Offs (4 required)
25	037546	Screw (2 required)
26	037545	Cup Support Locking Assembly
27	037547	Motor
28	030694	Top Motor Mount
29	037548	Screw (sems 2 required)

<b>Illustration#</b>	<b>Part#</b>	<b>Description</b>
30	030714	Spring Washer (2 required)
31	030696	Washer (2 required)
32	033697	Large Washer (2 required)
33	030697	Side Motor Mounts (2 required)
34	030706	Motor Ground Screw
35	030714	Spring Washer
36	037549	Washer
37	030707	Lock Washer
38	037550	Cord Clamp Screw (2 required)
39	030696	Washer (2 required)
40	033666	Cord Clamp
41	037551	Cord
42	031984	Strain Relief
43	033901	Cord Ground Screw
44	030714	Spring Washer
45	037549	Washer
46	030707	Lock Washer
47	037532	Hole Plug (6 required)
48	033901	Screw (6 required)
49	037552	Back Plate
50	037553	Rocker On/Off Switch
51	037965	Connector (2 required)
52	037966	Washer (2 required)
53	037967 037554	Bottom Plate with Weights Bottom Plate with Weights
54	036046	Feet (4 required)
55	030696	Washer (4 required)
56	030706	Screw (4 required)
57	037133	1.5" Screw (2 required)
58	030719	Suction Cup Feet (2 required)

Illustration#	Part#	Description
59	030696	Washer (2 required)
60	030706	Screw (2 required)
61	033901	Screw (2 required)
62	037555	Cup Actuator
63	037556	Cup Support
64	030716	Solid Disk
65	029291	Screw




Date Code Location →  
WWYY  
(week week year year)




**030716**  
Solid Agitator  
(hard ice cream)


**029291**  
Screw



**030883**  
Container



**029292**  
Butterfly Agitator  
(soft ice cream)



**037554**  
Bottom Plate with Weights