

Aladdin Temp-Rite®...better by degrees.

P.O. Box 2978, Hendersonville, TN 37077-2978
1-800-888-8018 or 615-537-3600
Fax 1-888-812-9956
www.aladdintemprite.com



**SR50, SR100
SRF5, SRF10
USR60, USR120**

STORAGE RACKS



MODEL SR50



MODEL USR60



MODEL SR100

Copyright © 2015 Aladdin Temp-Rite®

Changes may be made to the information in this document without notification.

CONTENTS

I. INTRODUCTION	4
II. SPECIFICATIONS	4
III. RECEIVING INSPECTIONS	5
IV. INSTALLATION	6
V. OPERATION	6
VI. CLEANING/MAINTENANCE	7
VII. TROUBLESHOOTING	7
VIII. PARTS LIST	8
OPTIONAL WASH RACKS	8
IX. WARRANTY & LIABILITY	10

I. INTRODUCTION

SR, SRF, & USR Series storage racks provide a convenient and practical way to wash, store and dry a variety of domes, bases and insulated trays. Removable wash racks designed specifically for Aladdin products are included - but we don't stop there. Extremely versatile in their design, our multi-purpose wash racks accommodate a variety of product types, including products from other manufactures.

Domes	Bases	Insulated trays
Allure® 9" entrée domes	Heat On Demand® 9" induction bases	Genie servers and cover (SR series only)
Essence™ 9" entrée domes	Most 9" insulated bases and base liners	
Dimensions® 9" high-heat domes	Insul-Max entrée bases	
Radiance 9" dome	Most stainless steel entrée bases	
Most 9" domes	Most base liners	

II. SPECIFICATIONS

	SRF5/ SR50 / USR60	SRF10 / SR100 / USR120
Length:	23.48" (59.6 cm)	44.48" (113 cm)
Width:	23.48" (59.6 cm)	23.48" (59.6 cm)
Height:	76.69" (194.8 cm)	76.69" (194.8 cm)
Weight:	38 lbs / 73 lbs / 58 lbs 17.2 kg / 33.11 kg / 26.3 kg	59 lbs / 129 lbs / 102 lbs 26.8 kg / 58.5 kg / 46.3 kg
Capacity	SRF5 5 wash racks SR50 50 domes USR60 60 domes or bases	SFR10 10 wash racks SR100 100 domes USR120 120 domes or bases

III. RECEIVING INSPECTIONS

Your Aladdin SR, SRF, or USR rack is factory tested for performance and is free from defects when shipped. The utmost care has been taken in packaging this product to protect against damage in transit.

You should carefully inspect your storage rack to assure that no damage has occurred in transit. If however, damage is detected see the following damaged goods policy. Under no condition may a damaged unit be returned to Aladdin Temp-Rite without first obtaining written permission (return authorization). No credit will be issued for claims not reported to Aladdin within ten (10) business days from receipt of shipment.

ALADDIN DAMAGED GOODS POLICY

There are two types of damaged merchandise:

- Visual Damage
- Concealed Damage

Visual Damage – When the product being received is visibly damaged.

1. Receiver should not accept merchandise with visual damage.
2. Receiver must sign delivery receipt “refused merchandise due to damage” and specify damage.
3. Receiver should call Aladdin Customer Service immediately after refusal.
4. Carrier will notify Aladdin Traffic Department and a claim will be filed.
5. Carrier will send acknowledgement of claim within 7 days after receiving.

Concealed Damage – When damaged merchandise cannot be externally detected.

Any receiving operation should be looking for this type of damage. Sometimes, however, depending on the type of product, it is almost impossible to notice.

1. Merchandise must not be removed from point of delivery and all packaging must be kept intact.
2. Receiver must contact Aladdin customer service to report damage.
3. Aladdin traffic department will request inspection based on the dollar value of the cargo.
4. Aladdin traffic department will file a claim based on the findings of the inspection.

Failure to comply with these policies will result in the customer’s responsibility to file claims.

The purchaser/user has the best knowledge and is in the best position to determine the operating conditions, appropriateness of the product for the operating environment, and safe use of the product. Aladdin Temp-Rite does not warrant, implied or expressly, that the product is fit for a particular use or operating environment.

IV. INSTALLATION

- Inspect exterior of box for damage. If any, see Section III Receiving inspection.
- Unbox unit
- Remove dome rack from pallet or skid
- Inspect dome rack for damage. If any, see Section III Receiving inspection.
- Remove manual from wire rack, keep for reference
- Check that brakes are unlocked, roll rack to desired location
- Dispose of packaging

V. OPERATION

- Use brakes to keep storage rack stationary while loading and unloading.
- Make sure wash racks are fully on stainless steel shelves before moving rack.
- Bases should NOT be double stack in racks, may shorten life of the product.



CAUTION



Do not place objects on top of rack.

Do not stand or climb on rack.

VI. CLEANING/MAINTENANCE



Harsh chemicals and insufficiently diluted sanitizers will damage chrome plated or stainless steel surface. Never use cleaning agents that contain phosphates or chlorides. These chemicals will cause permanent damage to chrome or stainless steel finish, and void equipment warranty.

Clean any debris from the frame or caster, then wipe complete unit with a damp cloth.

- Use warm water with mild detergent and soft cloth and dry.
- Use of high pressure sprayers or cart washing machines for cleaning will void the warranty

VII. TROUBLESHOOTING


COMPLAINT	PROBLEM	SOLUTION
Unit does not roll easily	Caster brake on	Check that all brakes are off
	Debris in caster	Clean caster housing and caster

VIII. PARTS LIST




#	Qty	Part Number	Description
1	4	12568	5" swivel caster w brake
2*	5	13639	USR wire rack (will fit racks made after 11/7/18)

OPTIONAL WASH RACKS



Sales code	PN	Description
J36V	11781	5 compartment, open front
K61	94672	5 compartment 1" ledge
K181	20341	4" height open rack
K182	20342	5.5" height open rack
K183	2034	5.5" height peg rack



FSR5 & SR50 & USR60



FSR10 & SR100 & USR120



IX . WARRANTY & LIABILITY

ALADDIN TEMP-RITE®
EQUIPMENT
LIMITED WARRANTY

Effective June, 2015

Aladdin Temp-Rite® (“ATR”) warrants to the original purchaser that the equipment listed below shall be free from defects in material and workmanship under normal use for the applicable warranty term set forth below. ATR’s obligation under this warranty is limited to the repair or replacement, at the sole option of ATR, of any part which upon inspection and examination by ATR or its authorized agent is found to be defective. A written description detailing the nature of the claimed defect, together with the equipment claimed to be defective if required by ATR, must be delivered to ATR or its authorized agent within 30 days of discovery of the claimed defect (but in no event later than 30 days after the expiration of the applicable warranty term).

EQUIPMENT	WARRANTY TERM*	
	PARTS	LABOR
SRF5, SRF10, USR60	1 year	90 days
SR50, SR100, USR120	1 year	90 days

*The warranty term commences 30 days after the date of ATR’s invoice for the equipment.

THE WARRANTIES AND REPRESENTATIONS OF ATR CONTAINED HEREIN ARE EXPRESSLY IN LIEU OF, AND THE BUYER WAIVES, ANY AND ALL OTHER WARRANTIES EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND ANY OTHER REMEDIES AGAINST ATR, WHETHER BASED UPON CONTRACT, NEGLIGENCE, STRICT LIABILITY OR OTHERWISE. ATR SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES OR ECONOMIC LOSS OF ANY NATURE (INCLUDING WITHOUT LIMITATION LOSS OF REVENUES AND/OR PROFITS) THAT MAY BE CLAIMED TO RESULT FROM ANY NEGLIGENCE OR BREACH OF WARRANTY OR CONTRACT BY ATR.

Exceptions and Exclusions

This warranty is issued only to the original purchaser, and is not transferable and applies only to the products installed within the United States of America, its territories and Canada. During the term of any labor warranty, ATR will pay all pre-approved shipping charges incurred in returning defective equipment to ATR and labor costs incurred in the removal and reinstallation of such equipment. Contact ATR before returning any defective equipment or otherwise performing any warranty repairs. ATR assumes no liability for any work or repair performed without its prior approval. After the expiration of any labor warranty, the original purchaser is responsible for all shipping charges incurred in returning defective equipment to ATR and labor for removing and reinstalling such equipment. ATR shall not be responsible for the replacement of expendable items like lamps and fuses or product failure resulting from normal wear and tear, improper installation, misuse, sabotage, abuse, neglect, accident, unauthorized alterations to repair, or other factors beyond the control of ATR. Neither this warranty, nor the liability of ATR may be modified or extended by action of any agent, distributor or other person or by custom or practice.

CALL ATR TOLL FREE AT 1-800-888-5426 IF YOU HAVE ANY QUESTIONS ABOUT THIS WARRANTY OR YOUR ATR PRODUCT.



250 East Main Street, Hendersonville, TN 37075

1-800-888-8018 • www.aladdintemprite.com • info@aladdin-atr.com