

Aladdin Temp-Rite® ...better by degrees.



P.O. Box 2978, Hendersonville, TN 37077-2978

1-800-888-8018 or 615-537-3600

Fax 1-888-812-9956

www.aladdintemprite.com

SS3L Stainless Steel Starter Station



Pans sold separately

Copyright © 2013 Aladdin Temp-Rite®

Changes may be made to the information in this document without notification.

CONTENTS

- I. SPECIFICATIONS 4
- II. RECEIVING INSPECTIONS 5
- III. SAFETY 6
- IV. INSTALLATION / OPERATION 6
- V. CLEANING 7
- VI. PARTS LIST 8
- VII . WARRANTY & LIABILITY 10

I. SPECIFICATIONS

Model Number	SS3L
Overall Length	42.8" (108.7 cm)
Overall Width	29.5" (74.8 cm)
Overall Height	66.4" (168.7 cm)
Shelf Dimensions:	
Top	41.5" x 16.68" (105.4 x 42.4 cm)
Middle	39.5" x 28.15" (100.3 x 71.5 cm)
Bottom	39.5" x 28.15" (100.3 x 71.5 cm)
Shelf Height from Floor:	
Top	36.4" (92.5 cm)
Middle	22.3" (56.6cm)
Bottom	8.2" (20.8 cm)
Shelf load capacity:	
Top	100 lbs (45.3 kg)
Middle	200 lbs (90.7 kg)
Bottom	200 lbs (90.7 kg)
Number of Interchangeable Pans Included	none
Shipping Weight (without pans)	115 lbs (55.2 kg)

Starter station accepts most standard food pans: full, half, and third sizes

II. RECEIVING INSPECTIONS

Your Aladdin SS3L starter station is factory tested for performance and is free from defects when shipped. The utmost care has been taken in packaging this product to protect against damage in transit.

You should carefully inspect your starter station to assure that no damage has occurred in transit. If however, damage is detected see the following damaged goods policy. Under no condition may a damaged unit be returned to Aladdin Temp-Rite without first obtaining written permission (return authorization). No credit will be issued for claims not reported to Aladdin within ten (10) business days from receipt of shipment.

ALADDIN DAMAGED GOODS POLICY

There are two types of damaged merchandise:

- Visual Damage
- Concealed Damage

Visual Damage – When the product being received is visibly damaged.

1. Receiver should not accept merchandise with visual damage.
2. Receiver must sign delivery receipt “refused merchandise due to damage” and specify damage.
3. Receiver should call Aladdin Customer Service immediately after refusal.
4. Carrier will notify Aladdin Traffic Department and a claim will be filed.
5. Carrier will send acknowledgement of claim within 7 days after receiving.

Concealed Damage – When damaged merchandise cannot be externally detected.

Any receiving operation should be looking for this type of damage. Sometimes, however, depending on the type of product, it is almost impossible to notice.

1. Merchandise must not be removed from point of delivery and all packaging must be kept intact.
2. Receiver must contact Aladdin customer service to report damage.
3. Aladdin traffic department will request inspection based on the dollar value of the cargo.
4. Aladdin traffic department will file a claim based on the findings of the inspection.

Failure to comply with these policies will result in the customer’s responsibility to file claims.

III. SAFETY

If you know how to correctly install, operate, clean and service the starter station your satisfaction with the equipment will be increased and safety will be enhanced. In accordance with generally accepted product safety labeling guidelines, the following three signal words are used throughout this manual to alert you to potential hazards and to tell you how to avoid them.

WARNING: The word "Warning" identifies a potentially hazardous situation. If not avoided this situation COULD result in death or serious personal injury.

CAUTION: The word "Caution" identifies a potentially hazardous situation. If not avoided this situation MAY result in minor or moderate injury. The word "Caution" may also be used to alert against unsafe practices and property damage only accidents.



"Important" is used to identify installation operation, or maintenance information which is important but not hazard related.

IV. INSTALLATION / OPERATION

INSTALLATION

- 1) Remove all packaging materials (keep until after step 2).
- 2) Inspect the unit (see section II RECEIVING INSPECTION)
- 3) Place pans on rack.
- 4) Position to desired location and then lock casters.

OPERATION



Starter station is for stationary use only

Do not stand on or use starter station as a ladder

Do not use as an Heat on Demand activator table

Do not place heavy objects on top of the starter station

HPP2, TPP2, HPP4, TPP4 FOOD PANS



Pans are for storage and organization of dry goods

Pans should not be heated

Pans should not be microwaved

TPP2
THIRD PAN



HPP2
HALF PAN



V. CLEANING




CLEANING

- Clean any debris from the casters
- Use warm water with a mild detergent and a soft cloth, then dry
- Using a high pressure sprayer or cart wash machine for cleaning will void the starter station warranty

CAUTION! - Harsh chemicals and insufficiently diluted sanitizer will damage stainless steel surfaces. Never use cleaning agents that contain phosphates or chlorides. These chemicals will cause permanent damage to stainless steel finishes and void equipment warranty.

VI. PARTS LIST

#	Qty	Part Number	Description
1	6	99839	cap, 1" tube
2*	-	12031	pan, half, 2.5", deep, black (sold in a case of 12)
3*	-	12032	pan, third, 2.5", deep, black (sold in a case of 12)
4*	-	12033	pan, half, 4", deep, black (sold in a case of 6)
5*	-	12034	pan, third, 4", deep, black (sold in a case of 12)
6	4	10160	screw, ss, 8-18 X3/4, SLFTPG
7	1	11791	top shelf, ss
8	2	11792	middle / bottom shelf, ss
9	2	99841	swivel caster with brake, 5"
10	2	93464	swivel caster, 5" stem
* not shown and sold separately			



NOTE: drawings shown without pans for clarity

VII . WARRANTY & LIABILITY

ALADDIN TEMP-RITE®
EQUIPMENT
LIMITED WARRANTY

Effective December, 2012

Aladdin Temp-Rite® (“ATR”) warrants to the original purchaser that the equipment listed below shall be free from defects in material and workmanship under normal use for the applicable warranty term set forth below. ATR’s obligation under this warranty is limited to the repair or replacement, at the sole option of ATR, of any part which upon inspection and examination by ATR or its authorized agent is found to be defective. A written description detailing the nature of the claimed defect, together with the equipment claimed to be defective if required by ATR, must be delivered to ATR or its authorized agent within 30 days of discovery of the claimed defect (but in no event later than 30 days after the expiration of the applicable warranty term).

EQUIPMENT	WARRANTY TERM*	
	PARTS	LABOR
SS3L Starter Station	one (1) year	ninety (90) days

*The warranty term commences 30 days after the date of ATR’s invoice for the equipment.

**The compressor warranty covers the compressor only and does not include any shipping charges, other transportation costs, any external parts or electrical components, labor, refrigerants and taxes.

THE WARRANTIES AND REPRESENTATIONS OF ATR CONTAINED HEREIN ARE EXPRESSLY IN LIEU OF, AND THE BUYER WAIVES, ANY AND ALL OTHER WARRANTIES EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND ANY OTHER REMEDIES AGAINST ATR, WHETHER BASED UPON CONTRACT, NEGLIGENCE, STRICT LIABILITY OR OTHERWISE. ATR SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES OR ECONOMIC LOSS OF ANY NATURE (INCLUDING WITHOUT LIMITATION LOSS OF REVENUES AND/OR PROFITS) THAT MAY BE CLAIMED TO RESULT FROM ANY NEGLIGENCE OR BREACH OF WARRANTY OR CONTRACT BY ATR.

Exceptions and Exclusions

This warranty is issued only to the original purchaser, and is not transferable and applies only to the products installed within the United States of America, its territories and Canada. During the term of any labor warranty, ATR will pay all pre-approved shipping charges incurred in returning defective equipment to ATR and labor costs incurred in the removal and reinstallation of such equipment. Contact ATR before returning any defective equipment or otherwise performing any warranty repairs. ATR assumes no liability for any work or repair performed without its prior approval. After the expiration of any labor warranty, the original purchaser is responsible for all shipping charges incurred in returning defective equipment to ATR and labor for removing and reinstalling such equipment. ATR shall not be responsible for the replacement of expendable items like lamps, fuses and **reusable pans**, or product failure resulting from normal wear and tear, improper installation, misuse, sabotage, abuse, neglect, accident, unauthorized alterations to repair, or other factors beyond the control of ATR. Neither this warranty, nor the liability of ATR may be modified or extended by action of any agent, distributor or other person or by custom or practice.

CALL ATR TOLL FREE AT 1-800-888-5426 IF YOU HAVE ANY QUESTIONS ABOUT THIS WARRANTY OR YOUR ATR PRODUCT.



250 East Main Street, Hendersonville, TN 37075

1-800-888-8018 • www.aladdintemprite.com • info@aladdin-atr.com